



Note: Fix all off sheet designators linked to this sheet

Note: All signals above are GPIO, connect to any GPIO bank, whichever is best for routing




Note: Interrupt pins, place on different pin numbers (same port okay), ease for routing





Δ

- Note: Fix all off sheet designators linked to this sheet
- Note: All signals above are DS, connect to any DS input, whichever is best for routing, including the DS adc on page 10



A

R

4

C

TEMP-BATT-B IN 44
VBATT-A IN 45
3.3V-A IN 56
3.3V-B IN 47
TEMP-REG-B IN 50
TEMP-REG-B IN 50
TEMP-REG-B IN 50
TEMP-LATE IN 41
TEMP-LATE IN 51
T

Note: Fix all off sheet designators linked to this sheet

Note: All signals above are SE, connect to any SE input, whichever is best for routing

