



Handy Services

4.9 from 300+ Reviews

OPS / BEN

07449 501 762

CONTRACTOR JOB SHEET • BEZENT

Job Sheet

Contractor: **Bezant**

Date: **Tuesday 30 June 2026** · 2 stops · about 6¾ hours total

£2M Public Liability

DBS Checked

Photo on Completion

STOP 1 OF 2

**74 St Stephen's Road,
Nottingham NG2 4JS**

Customer: **Tara**

Phone: **07989 432209**

 **About 2½ hours**

We bring the materials

1

Re-seal the bath with new silicone

About 1½ hours

Strip out all the old silicone around the bath. Clean and fully dry the joint, then put on fresh sanitary silicone in a clean, even line.

⚠ Important

Fill the bath with water before you seal it — the joint moves under the weight, so the seal stays good once it's emptied. Let it dry before it's used, and tell Tara how long to leave it.

2

Patch the hole in the kitchen ceiling

About 1 hour

Cut back to a firm edge, fit a plasterboard patch or scrim and filler depending on the size, fill it, then sand it back flush ready for paint.

⚠ Check first

Look above the hole for pipes or cables before cutting. If there's any sign of a leak, take a photo and call Ben before you patch it.

STOP 2 OF 2

2 Windsor Ave, Melbourne, Derby DE73 8FN

Customer: **Tam (Jane Howard)**

Phone: **07737 033462**

 **About 4¼ hours**

Customer supplies all the units

1

Install 3 kitchen cupboards

About 2 hours 45 minutes

Fit and secure the 3 kitchen cupboards (Tam provides these) to the wall and/or next to the other units. Mark, level, fix solid, then line up the doors and check they work.

Check first

Find out if they're wall or base units and what the wall is made of. Use the right fixings — cavity fixings for plasterboard, plugs for brick. Check for pipes and cables before drilling.

2

Fit a curtain pole or rail — 1 window

About 30 minutes

Mark and level the pole or rail (Tam provides it), then fix it solid so it holds the weight of the curtains. Make sure both brackets are even and secure.

3

Install the porch cupboard

About 1 hour

Position and fit the porch cupboard (Tam provides it). Level it and fix it solid to the wall. Check the doors sit square and open cleanly.

⚠ Check first

Porch walls can be thin or rendered block — test the fixing before you commit. Call Ben if the wall won't take a solid fixing.

Materials — Stop 1 only (we bring these)

1 tube Everbuild Sanitary Silicone, White 300ml
Bath re-seal — Stop 1, Task 1

1 Silicone remover gel
To strip the old bath silicone

1 Smoothing tool + cloths
Van kit — for a clean finish

1 each Ready-mix filler + scrim tape
Ceiling patch — Stop 1, Task 2

1 Plasterboard offcut 12.5mm
Only if the hole is too big to scrim

— Sandpaper (120 / 180 grit)
Sand the patch flush for paint

Stop 2 — bring your own fixings

Tam supplies all the units (kitchen cupboards, curtain pole, porch cupboard). You bring your fixings, brackets, wall plugs, cavity fixings, drill, level and pipe/cable detector. Check everything is on site before you start.

Before you set off

The two stops are about 22 miles apart (Nottingham → Melbourne, Derby) — allow around 40 minutes to drive between them. Ring each customer to make sure they're in before you head over. If Stop 1 runs late, text Ben so Tam can be told.

Photos to take

Stop 1 (Tara):

bath joint before & after · ceiling hole before · ceiling patched & sanded

Stop 2 (Tam):

each cupboard fitted & level · curtain pole up · porch cupboard installed