

NOTE: 1. WIRE IN EITHER HIGH SPEED OR LOW SPEED. NOT BOTH .

2. FAN CAN BE WIRED IN 2 SPEED. DO NOT USE STAR / DELTA SWITCH.

3. CHECK ROTATION OF UNIT IS AS PER LABEL ON FAN (OR WARRANTY IS VOID).

4. CHANGE ROTATION OF DIRECTION BY INTERCHANGING 2 PHASES

| REV. | DESCRIPTION | DATE | BY | 106 FAIRBANK ROAD CLAYTON SOUTH, VICTORIA 3169 | MAT'L / | FINISH: N/A | MODEL: |
|------|-------------------------|------------|-----|--|---------|----------------|--------------------------|
| А | ISSUED FOR CONSTRUCTION | 04.10.2020 | CFM | CFMAIRSYSTEMS CLAYTON SOUTH, VICTORIA 3169 ph: +61 3 9551 4878 email: mail@cfmairsystems.com.au web: www.cfmairsystems.com.au | DRAWN: | CFM Airsystems | DIAGRAM # 20 |
| | | | | COPIED OR DISCLOSED IN WHOLE OR IN PART, OR USED FOR MANUFACTURE OR FOR ANY OTHER PURPOSE I | DATE: | October 2020 | ·' |
| | | | | | | M.KOTSIKAS | DESCRIPTION: |
| | | | | | SCALE: | NTS | ELECTRICAL DIAGRAM No.20 |
| | | | | UNLESS OTHERWISE STATED DIMENSIONS ARE OUTSIDE DIMS, IN MILIMETRES AND TO TOLERANCES LINEAR: ±1 ANGLE: ±10' (MIN) HOLES: WITHIN 0.5 OF TRUE POSITION | SHEET: | A4 | REV A |