ESP32-DevKitC V4 w/ WROOM



** Require to burn the flash voltage eFuses for avoiding conflict between D2 & MTDI strapping*
***It is important to keep the sd card jumper wire very short (<= 2 inch)*
and plug them directly to the ESP32 pin (not via breadboard).
***It's critical for the 2 GND on the PMOD to be plug directly to the ESP32 GND pin via short wire!!*

Sheet: /
File: BlueRetro.sch

Title: BlueRetro DIY

Size: USLetter	Date: 2020-10-02	**Rev: v1.2**
KiCad E.D.A. kicad (5.1.6)-1		Id: 1/7