
moveArm() function

In the arduino code if you want to create animation or move any arms you must use moveArm() function the parameters are:

moveArm(Front leg left - X, Z, Y,/ Rear leg left - X, Z, Y/ Front leg right - X, Z, Y/ Rear leg right - X

Z, Y, Speed (between 1 to 100, 1 fast 100 very slow))

Front left leg (1st parameter)



Front right leg (3rd parameter)

Rear left leg (2nd parameter)

Rear right leg (4th parameter)

moveArm() function X Y Z positions

