Q1: In no more than three paragraphs, please describe the steps you took to setup remote connection. Using bullet points are much preferred.

- Using the Raspberry Pi with a Display, Mouse and Keyboard
  - o In the Preferences Menu open the Raspberry Pi Configurator
  - Open the Interfaces Tab
  - o Enable SSH
  - o Click OK
  - Open Terminal and get the Pi's IP Address using 'ifconfig'
    - If the IP is issued using DHCP you should set a static IP
- On the client system
  - o Install a suitable SSH client such as 'Putty' or another of your choice
  - o Enter the IP Address of your Raspberry Pi in the 'Hostname' textbox
  - o Check the port is correct, the SSH port is 22
  - Click connect
  - Authenticate using the Raspberry Pi Credentials
  - Start using the Raspberry Pi

Q2: Paste the screen capture here and submit the file as your submission for task 6.1P.

