

Help Menu

The commands are described under the [Help Menu](#).

Methods of the Marker

Methods of the Marker

The *Marker* provides the [Methods of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
contentsList	[]			((Contents:table)) -> any
createAttr				(NameOfUserDefinedAttribute:string, DataType:string) -> boolean
createIcon				(IconName:string, Width:integer, Height:integer) -> integer
deleteAttr				(NameOfUserDefinedAttribute:string) -> boolean

Name of the method Identifier and data type of the parameter you enter Data type of the return value

Name	Value	Inherited	Watchable	Signature
moveToFolder				(Folder:object) -> object
MU	VOID			((Index:integer:=1)) -> object
MUPart	VOID			((Index:integer:=1)) -> object

Name of the method Identifier and data type of the parameter you enter Default value Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

An example of the **Syntax** line of the individual methods might look like this:

```
<Path>.openDialog([CallOpenControl:boolean:=false]) → boolean
```

- The expression *<Path>* designates the path of the object to which the *method* applies.
- The signature of the method, consisting of the identifier and the data type of the parameter, is listed in parentheses. The expression *(Parameter:string)*, for example, designates a parameter of data type *string*. Instead of a constant value, you can also use a variable of the required type or a *method* that returns the required data type.

Note

Make sure to enter the parentheses for expressions within parentheses (...). Not entering them may lead to unexpected results and open the *Debugger*.

Optional parameters are listed within brackets. The expression *[,Parameter:boolean]*, for example, means that you can, but do not have to enter the *boolean* parameter.

If a parameter has a default value, the signature shows the default value after the parameter, *:= false* in the example above.

If the *method* has a return value, the signature shows its data type after the arrow *->*, *→ boolean* in the example above.

getRouteLength [SimTalk] - Marker

Returns the route length of the *Marker* designated by <Path> to the specified destination.

Type

Method

Syntax

```
<Path>.getRouteLength(ToMarker:path[, byref ObjectsAlongRoute:object[],  
RouteWeightingAttribute:string]) → length
```

Parameters

You can specify the following parameters:

- The parameter *ToMarker* of data type *path* designates the destination object.
- The optional parameter *ObjectsAlongRoute* designates an *array* of data type *object* into which the *Marker* enters the objects along the route to the destination.
- The optional parameter *RouteWeightingAttribute* of data type *string* designates the name of the **Route Weighting Attribute** for automatic routing. If the parameter is not passed, *Plant Simulation* does not weight the lengths of the routes.

Return Value

The return value has the data type *length*.

If the destination is not reachable, *Plant Simulation* returns the value -1.

Example

```
print Marker1.getRouteLength(Marker2)
```

Read-Only Attributes of the Marker

Read-Only Attributes of the Marker

The *Marker* provides the [_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.