

### Return Value

The method does not have a return value.

It outputs error messages, which might cause the method to fail, because:

- The specified *Worker* is a class object.
- The specified *Worker* is brokered automatically.
- The specified *Worker* cannot transport parts.
- The specified *Worker* already carries a part.
- The number of parts to be carried is greater than the current **Capacity** of the *Worker*.
- The part does not exist or does not have the correct object type.
- The **Destination** does not exist or does not have the correct object type.
- You did not specify a **Destination** and the part/the parts do not have a **Destination** of their own.
- The part itself, that is to be transported, has a defined **Destination**, which differs from the specified **Destination**.
- The parts to be transported have to be picked up at different locations.
- The part or one of the parts is already being transported by a *Worker*.
- No parts are to be picked up and carried away at the *Station* by the *Worker*.
- An error occurred while sending the *Worker* for picking up or transporting the parts.

### Examples

```
waituntil .Resources.Worker:1.HasOrder = false  
.Resources.Worker:1.transportPart(Station.cont, Station1)
```

### SimTalk

[cancelTransportPart \[SimTalk\]](#)

[Destination \[SimTalk\] - MUs](#)

## Read-Only Attributes of the Worker

### \_Read-Only Attributes of the Worker

The *Worker* provides:

- The *read-only attributes* listed in the table of contents to the left.
- All *read-only attributes* of the *Exporter*, as the *Worker* is an *Exporter* with the capacity of 1.

- The [\\_Read-Only Attributes of All Objects](#).

You can query the values of the *read-only attributes*, but you cannot set them as *Plant Simulation* computes the value for the point-in-time at which you query it. In most cases a *read-only attribute* corresponds to an unavailable dialog item on one of the tabs of the object, for example on the tab **Statistics**.

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

| Name               | Value | Inherited | Watchable | Signature  |
|--------------------|-------|-----------|-----------|------------|
| NumPartsSinceSetup | 0     |           |           | -> integer |
| NumPred            | 1     |           |           | -> integer |
| NumSucc            | 3     |           |           | -> integer |

Name of the read-only attribute      Current value of the read-only attribute      Data type of the return value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print .Resources.Worker:1.StatTraveledDistance
```

## AvailableForMediation [SimTalk] - Worker

Returns if the *Worker* designated by <Path> can be brokered to do a job (true) or not (false).

### Type

Read-only attribute

### Syntax

```
<Path>.AvailableForMediation → boolean
```

### Watchable

The read-only attribute is [watchable](#).

### Return Value

The return value has the data type *boolean*.

true if the *Worker* is not failed, not paused, does not carry parts, and if he is not brokered.

### Example

```
print .Resources.MyWorker:2.AvailableForMediation
```

## CurrentSpeed [SimTalk] - Worker

Returns the **Current Speed** with which the *Worker* designated by >Path> walks on the *Footpath* or *freely within the area*.

### Type

Read-only attribute

### Syntax

```
<Path>.CurrentSpeed → speed
```

### Watchable

The read-only attribute is [watchable](#).

By watching it, you might, for example detect the event when the speed of a *Worker* changes.

### Return Value

The return value has the data type *speed*.

It is the **Speed** which you set.

0 if the *Worker* is **failed** or **stopped** or if he is located in the *WorkerPool* or on a *Workplace*.

### Example

```
print .UserObjects.MyWorker:1.CurrentSpeed
```

### See also

[Speed \[Worker\]](#)

## HasOrder [SimTalk] - Worker

Returns if the *Worker* designated by <Path> has the order to transport parts, currently transports parts, or just exports services.

### Type

Read-only attribute

### Syntax

```
<MU-Path>.HasOrder -> boolean
```

### Watchable

The attribute is **watchable**.

### Return Value

The return value has the data type *boolean*.

### Example

```
waituntil not Worker.HasOrder    // wait until the Worker is idle, has no  
order, or carries no parts  
  mu.move                        // transfer the MU, which should place an  
order for the Worker to transport it
```

## ResCurrentState [SimTalk] - Worker

Returns the **Current State** of the *Worker* designated by <Path>.

### Remarks

During a simulation run the *Worker* can take on one of these states as described on the **Tab Statistics: Services Setting-up, Services Processing, Services Repairing, Services Transporting, Services En-route to Job, Services Waiting, Exporter Paused, Exporter Unplanned, or Exporter failed.**

### Note

If two states occur at the same time, for example **Paused** and **Failed**, the read-only attribute returns the state that also has precedence for statistics collection. **Paused** for example for **Paused** and **Failed**.

### Type

Read-only attribute

### Syntax

```
<Path>.ResCurrentState → string
```

### Watchable

The read-only attribute is [watchable](#).

Use it in **waituntil-instructions** or to make the object *TimeSequence* record it in *watch* mode.

### Return Value

The return value has the data type *string*.

VOID if **Exporter statistics** is turned off.

### Example

```
print .Resources.John.ResCurrentState -- class
print .Resources.John:1.ResCurrentState -- instance
```

### See also

[Resource Statistics \[material flow objects\]](#)

**Tab Statistics [Worker]**

## StatServicesEnRouteIdleCount [SimTalk]

Returns how often the *Worker* designated by <Path> was on his way without having an order.

### Remarks

The overall statistics time is the statistics collection time without the **Unplanned Time** and the **Paused Time**.

This means that he was on his way, while he could be brokered. This occurs, for example, if you clear **Get Job Orders at Home Only** and also clear **Worker Stays Here After Completing the Job** at the *Workplace*. If you send the *Worker* to a *Workplace* with the method *goTo*, then this will also be added to the value *StatServicesEnRouteIdleCount*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesEnRouteIdleCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesEnRouteIdleCount
```

### SimTalk

[goTo \[SimTalk\]](#)

### See also

[Get Job Orders At Home Only](#)

[Worker Stays Here After Completing the Job](#)



## StatServicesEnRouteIdlePortion [SimTalk]

Returns the portion of the overall statistics time during which the *Worker* designated by <Path> was en-route without being assigned a job order.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

This means that he was on his way, while he could be brokered. This occurs, for example, if you clear **Get Job Orders at Home Only** and also clear **Worker Stays Here After Completing the Job** at the *Workplace*. If you send the *Worker* to a *Workplace* with the method *goTo*, then the time he was on this way will also be added to the value *StatServicesEnRouteIdlePortion*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesEnRouteIdlePortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesEnRouteIdlePortion
```

### SimTalk

[goTo \[SimTalk\]](#)

See also

[Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

[Get Job Orders At Home Only](#)

[Worker Stays Here After Completing the Job](#)

## StatServicesEnRouteIdleTime [SimTalk]

Returns the total time during which the *Worker* designated by <Path> was en-route without having a job.

### Remarks

This means that he was on his way, while he could be brokered. This occurs, for example, if you clear **Get Job Orders at Home Only** and also clear **Worker Stays Here After Completing the Job** at the *Workplace*. If you send the *Worker* to a *Workplace* with the method *goTo*, then the time he was on this way will also be added to the value *StatServicesEnRouteIdlePortion*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesEnRouteIdleTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesEnRouteIdleTime
```

### SimTalk

#### [goTo \[SimTalk\]](#)

#### See also

#### [Get Job Orders At Home Only](#)

#### [Worker Stays Here After Completing the Job](#)

## StatServicesEnRouteToJobCount [SimTalk]

Returns how often the *Worker* designated by <Path> was en-route to a *Workplace*, to which he was brokered for do a job at the associated station.

### Remarks

If you select **Get Job Orders at Home Only**, *Plant Simulation* also counts how often the *Worker* walked back to the *WorkerPool* to get the next order.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesEnRouteToJobCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesEnRouteToJobCount
```

### See also

[Get Job Orders At Home Only](#)

## StatServicesEnRouteToJobPortion [SimTalk]

Returns the portion of the overall statistics time during which the *Worker* designated by <Path> was en-route to a *Workplace*, to which he was brokered to do a job at the associated station.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

If you select **Get Job Orders at Home Only**, *Plant Simulation* also counts the time during which the *Worker* walked back to the *WorkerPool* to get the next order.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesEnRouteToJobPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesEnRouteToJobPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

#### [Get Job Orders At Home Only](#)

## StatServicesEnRouteToJobTime [SimTalk]

Returns the total time during which the *Worker* designated by <Path> was en-route to a *Workplace* for which he was brokered to do a job at the associated station.

### Remarks

If you select **Get Job Orders at Home Only**, *Plant Simulation* also counts the time during which the *Worker* walked back to the *WorkerPool* to get the next order.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesEnRouteToJobTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesEnRouteToJobTime
```

### See also

[Get Job Orders At Home Only](#)

## StatServicesFailedCount [SimTalk] - Worker

Returns how often the services of the *Worker* designated by <Path> were failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesFailedCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesFailedCount
```

## StatServicesFailedPortion [SimTalk] - Worker

Returns the portion of the failed time of the services of the overall statistics time of the *Worker* designated by <Path>.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesFailedPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesFailedPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

## StatServicesFailedTime [SimTalk] - Worker

Returns the total time during which services of the *Worker* designated by <Path> were failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesFailedTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesFailedTime
```



## StatServicesRepairingCount [SimTalk] - Worker

Returns how often the services of the *Worker* designated by <Path> worked on repairs.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesRepairingCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesRepairingCount
```

## StatServicesRepairingPortion [SimTalk] - Worker

Returns the portion of the repairing time of the *services* of the overall statistics time of *Worker* designated by <Path>.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesRepairingPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesRepairingPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

## StatServicesRepairingTime [SimTalk] - Worker

Returns the total time which the *services* of the *Worker* designated by <Path> spent for repairs.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesRepairingTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesRepairingTime
```

## StatServicesSetupCount [SimTalk] - Worker

Returns how often the services of the *Worker* designated by <Path> were setting the station up.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesSetupCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesSetupCount
```

## StatServicesSetupPortion [SimTalk] - Worker

Returns the portion of the set-up time of the services of the overall statistics time of the *Worker* designated by <Path>.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Note

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesSetupPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesSetupPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

## StatServicesSetupTime [SimTalk] - Worker

Returns the total time the services of the *Worker* designated by <Path> were setting the station up.

### Remarks

If a station fails and/or is unplanned or paused and services for setting-up or processing are brokered for this station, the services remain assigned. For this reason the set-up time and the processing time for the services continues while the station is failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesSetupTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesSetupTime
```

## StatServicesTransportingCount [SimTalk]

Returns how often the *Worker* designated by <Path> was carrying parts from *Workplace* to *Workplace*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesTransportingCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesTransportingCount
```

## StatServicesTransportingPortion [SimTalk]

Returns the portion of the overall statistics time during which the *Worker* designated by <Path> was carrying parts from *Workplace* to *Workplace*.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesTransportingPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesTransportingPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)



## StatServicesTransportingTime [SimTalk]

Returns the total time during which the *Worker* designated by <Path> was carrying parts from *Workplace* to *Workplace*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesTransportingTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesTransportingTime
```

## StatServicesWaitingImpCount [SimTalk] - Worker

Returns how often the *services* of the *Worker* designated by <Path> waited for an *importer*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingImpCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingImpCount
```

## StatServicesWaitingImpPortion [SimTalk] - Worker

Returns the portion of the overall statistics time which the *services* of the *Worker* designated by <Path> spent waiting for an *importer*, weighted with the capacity.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingImpPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingImpPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

## StatServicesWaitingImpTime [SimTalk] - Worker

Returns the total waiting time of the *services* of the *Worker* designated by <Path> for an *importer*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingImpPortion → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingImpPortion
```

## StatServicesWaitingMUCount [SimTalk] - Worker

Returns how often the *services* of the *Worker* designated by <Path> spent waiting for a *MU* at the *importer*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingMUCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingMUCount
```

## StatServicesWaitingMUPortion [SimTalk] - Worker

Returns the portion of the overall statistics time during which the *services* of the *Worker* designated by <Path> were waiting for a *MU* at the *importer*.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingMUPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingMUPortion
```

### See also

### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

## StatServicesWaitingMUTime [SimTalk] - Worker

Returns the total time the *services* of the *Worker* designated by <Path> were waiting at the *importer* for a *MU*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingMUTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingMUTime
```

## StatServicesWaitingPortion [SimTalk] - Worker

Returns the portion of the waiting time of the services of the overall statistics time of the *Worker* designated by <Path>.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

#### Note

The value of *StatServicesWaitingPortion* is the sum of *StatServicesWaitingImpPortion* plus *StatServicesWaitingMUPortion*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingPortion
```

### SimTalk

[StatServicesWaitingImpPortion \[SimTalk\] - Worker](#)

[StatServicesWaitingMUPortion \[SimTalk\] - Worker](#)



## StatServicesWaitingTime [SimTalk] - Worker

Returns the time which the *services* of the *Worker* designated by <Path> were waiting in relation to the statistics collection period.

### Remarks

The value of *StatServicesWaitingTime* is the sum of *StatServicesWaitingImpTime* and *StatServicesWaitingMUTime*.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWaitingTime → time
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:2.StatServicesWaitingTime
```

### SimTalk

[StatServicesWaitingImpTime \[SimTalk\] - Exporter](#)

[StatServicesWaitingMUTime \[SimTalk\] - Exporter](#)

## StatServicesWorkingCount [SimTalk] - Worker

Returns the number of working processes which the *services* of the *Worker* designated by <Path> provided.

### Remarks

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWorkingCount → integer
```

### Return Value

The return value has the data type *integer*.

### Example

```
print .Resources.MyWorker:1.StatServicesWorkingCount
```

## StatServicesWorkingPortion [SimTalk] - Worker

Returns the working portion of the *services* of the overall statistics time of the *Worker* designated by <Path>.

### Remarks

The overall statistics time is the statistics collection period without the **Unplanned Time** and the **Paused Time**.

### Note

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWorkingPortion → real
```

### Return Value

The return value has the data type *real*.

### Example

```
print .Resources.MyWorker:1.StatServicesWorkingPortion
```

### See also

#### [Tab Statistics \[Worker\]](#)

*Statistics report*, [Service Statistics — States — Time Portions of the Exporters](#)

## StatServicesWorkingTime [SimTalk] - Worker

Returns the time taken up by working processes of the *services* of the *Worker* designated by <Path>.

### Remarks

If a station changes to the state **failed** and/or **unplanned** or **paused** and if then services for setting-up or processing are brokered, the services remain brokered. The set-up time and the processing time for the services thus continues while the station is failed.

### Type

Read-only attribute

### Syntax

```
<Path>.StatServicesWorkingTime → real
```

### Return Value

The return value has the data type *time*.

### Example

```
print .Resources.MyWorker:1.StatServicesWorkingTime
```

## StatTraveledDistance [SimTalk] - Worker

Returns the distance which the instance of the *Worker* designated by <Path> covered while walking from the *WorkerPool* to the *Workplaces* attached to the stations and between the stations in meters.

## Type

Read-only attribute

## Syntax

```
<Path>.StatTraveledDistance → length
```

## Return Value

The return value has the data type *length*.

## Example

```
print .Resources.MyWorker:2.StatTraveledDistance
```

## See also

[Tab Statistics \[Worker\]](#)

*Statistics report*, [Worker Statistics — Traveled Distance by Workers](#)

## Attributes of the Worker

\_Attributes of the Worker

The *Worker* provides:

- The *attributes* listed in the table of contents to the left.

**Note**

If you do not use a [FootPath](#), *Plant Simulation* beams the *Worker* to the *Workplace*.

- The [\\_Attributes of the Exporter](#) as the *Worker* is an [Exporter \[object\]](#) with the capacity of 1.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.