


Find Any Value within a List or Table

You can find any text or value contained in an object of type list or table which you inserted into your simulation model.

Proceed as follows:

1. Select **Table** from the left drop-down list.
2. Enter any text or any value contained within a list or table in the search scope.



3. Repeat steps 4 to 7 described under [Find the Name of an Object](#).
4. Click **Find**.

Back to [Find Objects and Text in Your Simulation Model](#)

Modeling the Material Flow

Modeling the Material Flow

Introduces you to the most important tasks you will face when you create your simulation model in *Plant Simulation*.

Go to [Creating a Simulation Model](#)

Go to [Update Arbitrary Old Models](#)

Go to [Open an Old Model in a Newer Version](#)

Go to [Model the Flow of Materials, Basics](#)

Go to [Model the Flow of Materials, Advanced](#)

Go to [Simulate Free-flowing Materials and Fluids](#)

Go to [Simulate the Accrued Costs of the Machines](#)

Go to [Simulate the Power Consumption in Your Facility](#)

Go to [Model Workers and the Jobs They Do](#)

Go to [Model a Shift System](#)

Go to [Model a Lockout Zone](#)

Go to [Assemble Parts with the AssemblyStation](#)

Go to [Remove Parts with the Dismantle Station](#)

Go to [Pick and Place Parts with the PickAndPlace Robot](#)

Go to [Convey Parts Laterally with the Converter](#)

Go to [Change the Conveying Direction with the AngularConverter](#)

Go to [Align and Shrink-Wrap Parts with the Turnplate](#)

Go to [Move Parts On with the Turntable](#)

Go to [Model Transport Systems](#)

Go to [Prepare Data for the Simulation with DataFit](#)

Go to [Run Simulation Experiments](#)

Go to [Pack a Model and Send It to Another User](#)

Compare [Visualizing the Material Flow](#)

Compare [Animate the Simulation Model and View the Results](#)

Compare [Getting to Know Plant Simulation](#)