

注意:

- 1. 先安装好 PL2302 USB 转串口驱动,转备好 USB 线,连接计算机与协调器模块模块。
- 2. 需要两个或两个以上模块。

• 实验目的:


学习如何使用 TI 提供的协议栈,组成无线传感器网络,并实现自组网与无线数据传输。其中一个模块为协调器,其他模块为无线终端。一个网络只有一个协调器,可以有多个无线终端。

实验现象:

- 1. 无线终端上电以后,自动搜索附近是否有协调器,如果没有,过一段时间后重新搜索;如果有则向协调器申请加入网络,协调器自动向无线终端分配一个 16 位的地址,组网成功后,无线终端的蓝色 LED 常亮;
- 2. 其他无线终端上电以后,以同样的方式申请加入这个网络,协调器自动分配没一个无线终端一个不同的地址;
- 3. 无线终端每隔 3 秒向协调器发送一组数据;
- 4. 协调器接收所有无线终端发送过来的数据,并把每个无线终端的地址和 发送过来的数据通过串口发送到电脑,显示出来。

• 实验步骤:


1. 打开工程文件: Projects\zstack\Samples\无线传感器网络(自组网)\CC2530DB,选择 EndDeviceEB-Pro,下载到每一个无线终端模块中;(作为终端设备无线发送数据给协调器),如下图所示。



2. 选择 CoodinatorEB-Pro, 下载到协调器模块中;(作为协调器串口跟电脑连接),并连接 USB 线。如下图所示。

易思开发工作室 ES Technology

http://es-tech.taobao.com



- 3. 使用 USB 数据线连接协调器与计算机,打开串口调试助手,设置好参数, 打开协调器电源。
- 4. 分别打开所有无线终端的电源。可以看到串口调试助手每隔 3 秒左右便 收到一次数据,如下图所示:



具体实验: (发送部分)

```
1. 登记事件,设置编号、发送时间等
uint16 SampleApp ProcessEvent( uint8 task id, uint16 events )
  afIncomingMSGPacket_t *MSGpkt;
  (void)task id; // Intentionally unreferenced parameter
  if (events & SYS EVENT MSG)
    MSGpkt = (afIncomingMSGPacket_t *)osal_msg_receive( SampleApp_TaskID );
    while (MSGpkt)
    {
      switch (MSGpkt->hdr.event)
      {
        case CMD_SERIAL_MSG:
        SampleApp SerialCMD((mtOSALSerialData t *)MSGpkt);
        break;
        // Received when a key is pressed
        case KEY_CHANGE:
          SampleApp_HandleKeys( ((keyChange_t *)MSGpkt)->state,
((keyChange_t *)MSGpkt)->keys);
          break;
        // Received when a messages is received (OTA) for this endpoint
        case AF_INCOMING_MSG_CMD:
          SampleApp_MessageMSGCB( MSGpkt );
          break;
        // Received whenever the device changes state in the network
        case ZDO_STATE_CHANGE:
          SampleApp_NwkState = (devStates_t)(MSGpkt->hdr.status);
          if ( (SampleApp NwkState == DEV ZB COORD)
               || (SampleApp_NwkState == DEV_ROUTER)
               | | (SampleApp NwkState == DEV END DEVICE) )
          {
```

```
// Start sending the periodic message in a regular interval.
              osal_start_timerEx( SampleApp_TaskID,
                                   SAMPLEAPP_SEND_PERIODIC_MSG_EVT,
                                   SAMPLEAPP_SEND_PERIODIC_MSG_TIMEOUT);
           }
           else
           {
             // Device is no longer in the network
           }
           break;
         default:
           break;
       }
       // Release the memory
       osal_msg_deallocate( (uint8 *)MSGpkt );
       // Next - if one is available
       MSGpkt = (afIncomingMSGPacket_t
*)osal_msg_receive( SampleApp_TaskID );
    }
    // return unprocessed events
    return (events ^ SYS_EVENT_MSG);
  }
  // Send a message out - This event is generated by a timer
  // (setup in SampleApp_Init()).
  if ( events & SAMPLEAPP_SEND_PERIODIC_MSG_EVT )
    // Send the periodic message
    SampleApp_SendPeriodicMessage();
    // Setup to send message again in normal period (+ a little jitter)
    osal_start_timerEx( SampleApp_TaskID,
SAMPLEAPP_SEND_PERIODIC_MSG_EVT,
```

```
(SAMPLEAPP_SEND_PERIODIC_MSG_TIMEOUT + (osal_rand() & 0x00FF)) );
// return unprocessed events
  return (events ^ SAMPLEAPP_SEND_PERIODIC_MSG_EVT);
}
// Discard unknown events
return 0;
}
```

解释:

- **1.1** SampleApp_TaskID 为任务 ID, 函数开头定义了 SampleApp_TaskID = task_id;也就 是 SampleApp 初始化的任务 ID 号。
- **1.2 SAMPLEAPP_AA_PERIODIC_MSG_EVT** 为登记任务事件,同一个任务下可以有多个事件,这个是事件的号码。我们可以定义自己的事件,但是编号不能重复。文件定义了#define SAMPLEAPP_SEND_PERIODIC_MSG_EVT 0x0001
- **1.3 SAMPLEAPP_AA_PERIODIC_MSG_TIMEOUT** 为事件重复执行的时间。这里可以你需要发送数据的时间间隔。文件中定义了**#define**

SAMPLEAPP_SEND_PERIODIC_MSG_TIMEOUT 3000, 这里以毫秒为单位,所以是 3s, 也就是刚刚实验为什么隔约 3s 收到数据的原因。

2. 周期性发送数据函数

解析:

其中发送的数据储存在 data 数组里。

具体实验: (接收部分)

1. 读取数据并把发送到电脑函数 void SampleApp MessageMSGCB(afIncomingMSGPacket t*pkt) uint8 asc 16[16]={'0','1','2','3','4','5','6','7','8','9','A','B','C','D','E','F'}; uint16 flashTime,temp; uchar receive data[10]; switch (pkt->clusterId) { case SAMPLEAPP_POINT_TO_POINT_CLUSTERID: temp=pkt->srcAddr.addr.shortAddr; //读出数据包的 16 位短地址 for(i=0;i<10,i++) receive data[i]=pkt->cmd.Data[i] //读出数据(每次 10 个) HalUARTWrite(0,"ENDDEVICE ShortAddr:0x",22); //串口显示 /****将短地址分解,通过串口显示出来****/ HalUARTWrite(0,&asc 16[temp/4096],1); HalUARTWrite(0,&asc 16[temp%4096/256],1); HalUARTWrite(0,&asc_16[temp%256/16],1); HalUARTWrite(0,&asc 16[temp%16],1); HalUARTWrite(0," Reveive data: ",22); //串口显示 /****将接收到的第一个分解,通过串口显示出来****/ HalUARTWrite(0,&asc 16[temp%1000/100],1); HalUARTWrite(0,&asc 16[temp%100/10],1); HalUARTWrite(0,&asc 16[temp%10],1); // 回车换行 HalUARTWrite(0,"\n",1); break; case SAMPLEAPP FLASH CLUSTERID: flashTime = BUILD_UINT16(pkt->cmd.Data[1], pkt->cmd.Data[2]); HalLedBlink(HAL_LED_4, 4, 50, (flashTime / 4)); break; } }

解释:

} afMSGCommandFormat t;

```
所有的数据和信息都在函数传入来的 afIncomingMSGPacket_t *pkt 里面,进
入 afIncomingMSGPacket_t 的定义,它是一个结构体,内容如下:
typedef struct
 osal event hdr t hdr;
                        /* OSAL Message header */
                          /* Message's group ID - 0 if not set */
 uint16 groupId;
 uint16 clusterId:
                          /* Message's cluster ID */
 afAddrType_t srcAddr;
                          /* Source Address, if endpoint is
STUBAPS INTER PAN EP,
                             it's an InterPAN message */
 uint16 macDestAddr;
                          /* MAC header destination short address */
 uint8 endPoint:
                          /* destination endpoint */
 uint8 wasBroadcast;
                          /* TRUE if network destination was a broadcast
address */
 uint8 LinkQuality;
                          /* The link quality of the received data frame
*/
 uint8 correlation;
                          /* The raw correlation value of the received
data frame */
 int8 rssi;
                          /* The received RF power in units dBm */
 uint8 SecurityUse;
                          /* deprecated */
                          /* receipt timestamp from MAC */
 uint32 timestamp;
 afMSGCommandFormat t cmd; /* Application Data */
} afIncomingMSGPacket t;
里面包含了数据包的所有东西,长地址、短地址、RSSI等。其中洪湖数据在
afMSGCommandFormat t cmd 里面。
typedef struct
        TransSeqNumber;
 byte
 uint16 DataLength;
                                // Number of bytes in TransData
 byte *Data:
```