

RS-30 Rotary Screw Compressor - Instruction Manual

Section 1. Safety instructions

Read this manual before operating the RS-30 unit.

Section 4. Maintenance

4.2 Cylinder head bolts

La coppia di serraggio della testata è di 85 Nm.

Tighten the cylinder head bolts to a torque of 85 Nm.