


Fortnite

QuadStick profile reference — ddfortnite.csv

Modes	Console names	Output
7	PlayStation	USB



■ Sip = draw air in ■ Puff = blow out

A soft sip or puff is gentle — the QuadStick beeps. A hard one is firm — it clicks. Left + Center means sip or puff on both holes at once.

Modes in this profile

1	Left joy Left joy	●○○○○
2	Left joy Left joy	○●○○○
3	Right joy Right joy	○○●○○
4	Left joy Left joy	○○○●○
5	D-Pad D-Pad	○○○○●
6	Left joy Left joy	●○○○●
7	Left joy Left joy	○●○○●

The five lights show which mode is active. After mode 5 the last light stays on and the count starts again.

Changing mode

- Side tube sip → Mode +
- Side tube puff → Mode –

To change to a different profile file: long hard sip on the side tube, move the joystick until the lights show the file you want, then press the lip.



Left joy

Fortnite — Left joy



	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff						
Puff	L1 Previous weapon	L3 Sprint	R2 Fire	R3 Harvesting tool	R1 Next weapon	Mode - Previous mode
Sip	X Jump	L3 Sprint R3 Harvesting tool	L2 Aim down sights		Δ Switch to build mode	Mode + Next mode
Soft sip	○ Crouch / slide		PS PS home			

Joystick

- Left stick Move (forward, back, left, right)

Chin switch

Press

☐

Reload (hold: interact)

Free inputs in this mode: mp_left_puff_soft mp_left_center_sip_soft mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip mp_right_center_sip_soft mp_right_center_puff_soft mp_right_sip_soft mp_right_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2

	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff						
Puff	L1 Previous weapon	L3 Sprint	R2 Fire	R3 Harvesting tool	R1 Next weapon	Mode - Previous mode
Sip	X Jump	L3 Sprint R3 Harvesting tool	L2 Aim down sights Mode + Next mode		Δ Switch to build mode	Mode + Next mode
Soft sip	○ Crouch / slide		PS PS home			

Joystick

- Left stick Move (forward, back)
- Right stick Look (left, right)

Chin switch

Press

☐ Reload (hold: interact)

Free inputs in this mode: mp_left_puff_soft mp_left_center_sip_soft mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip mp_right_center_sip_soft mp_right_center_puff_soft mp_right_sip_soft mp_right_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2

	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff						
Puff	L1 Previous weapon	L3 Sprint	R2 Fire	R3 Harvesting tool	R1 Next weapon	Mode – Previous mode
Sip	X Jump	L3 Sprint R3 Harvesting tool	L2 Aim down sights Mode – Previous mode		△ Switch to build mode	Mode + Next mode
Soft sip	○ Crouch / slide		PS PS home			

Joystick

- Right stick Look (forward, back, left, right)

Chin switch

Press

☐Reload (hold: interact)

Free inputs in this mode: mp_left_puff_soft mp_left_center_sip_soft mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip mp_right_center_sip_soft mp_right_center_puff_soft mp_right_sip_soft mp_right_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2

	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff	Share Share / Create R3 after delay Harvesting tool				Touchpad Map	
Puff	L2 toggle Aim down sights		R1 Next weapon	△ Switch to build mode	× Jump	Mode − Previous mode
Sip	L1 Previous weapon	L1 Previous weapon R1 Next weapon	□ Reload (hold: interact)	R3 Harvesting tool	○ Crouch / slide	Mode + Next mode
Soft sip	Share Share / Create		PS PS home		Options Game menu	

Joystick

- Right stick Look (forward, back)
- Left stick Move (left, right)

Chin switch

Press

R2

Fire

Free inputs in this mode: mp_left_center_sip_soft mp_left_center_puff mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip_soft mp_right_center_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2

	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff	Share Share / Create R3 after delay Harvesting tool				Touchpad Map	
Puff	L2 toggle Aim down sights		○ Crouch / slide	△ Switch to build mode	× Jump	Mode – Previous mode
Sip	L1 Previous weapon	L3 Sprint L1 Previous weapon R1 Next weapon	□ Reload (hold: interact)	R3 Harvesting tool	R1 Next weapon	Mode + Next mode
Soft sip	Share Share / Create		PS PS home		Options Game menu	

Joystick

- **D-pad** N Place marker, NE, E Inventory, SE, S Emote wheel, SW, W Push to talk, NW

Chin switch

Press

R2
Fire

Free inputs in this mode: mp_left_center_sip_soft mp_left_center_puff mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip_soft mp_right_center_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2

	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff	Share Share / Create R3 after delay Harvesting tool				Touchpad Map	
Puff	L2 toggle Aim down sights		R1 Next weapon	△ Switch to build mode	R2 Fire	Mode − Previous mode
Sip	L1 Previous weapon	L1 Previous weapon R1 Next weapon	□ Reload (hold: interact)	R3 Harvesting tool	○ Crouch / slide	Mode + Next mode
Soft sip	Share Share / Create		PS PS home		Options Game menu	

Joystick

- Left stick Move (forward, back)
- Right stick Look (left, right)
- Pushing forward also holds

L3

Sprint

Chin switch

Press

X

Jump

Free inputs in this mode: mp_left_center_sip_soft mp_left_center_puff mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip_soft mp_right_center_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2

	Left	Left + Center	Center	Right + Center	Right	Side tube
Soft puff	Share Share / Create R3 after delay Harvesting tool				Touchpad Map	
Puff	L2 toggle Aim down sights		R2 Fire	△ Switch to build mode	R1 Next weapon	Mode − Previous mode
Sip	L1 Previous weapon	L1 Previous weapon R1 Next weapon	□ Reload (hold: interact)	R3 Harvesting tool	○ Crouch / slide	Mode + Next mode
Soft sip	Share Share / Create		PS PS home		Options Game menu	

Joystick

- **Left stick** Move (forward, back)
- **Right stick** Look (left, right)
- Pushing **forward** also holds

L3

Sprint

Chin switch

Press

X

Jump

Free inputs in this mode: mp_left_center_sip_soft mp_left_center_puff mp_left_center_puff_soft mp_center_puff_soft mp_right_center_sip_soft mp_right_center_puff_soft mp_left_right_sip mp_left_right_sip_soft mp_left_right_puff mp_left_right_puff_soft mp_triple_sip mp_triple_sip_soft mp_triple_puff mp_triple_puff_soft right_sip_soft right_puff_soft lip_soft digital_in_1 digital_in_2