1、测试程序段

1、测试性		指令代码						
地址	op(6) rs(5) rt(5) rd(5)/immediate (16) 16 进制数代码							
0x00000000	addi \$1,\$0,8	001000	00000	00001	0000 0000 0000 1000	=	2001 0008	
0x00000004	ori \$2,\$0,2	001101	00000	00010	0000 0000 0000 0010	=	3402 0002	
0x00000008	add \$3,\$2,\$1	000000	00010	00001	00011 00000 100000	=	0041 1820	
0x000000C	sub \$5,\$3,\$2	000000	00011	00010	00101 00000 100011	=	0062 2823	
0x0000010	and \$4,\$5,\$2	000000	00101	00010	00100 00000 100100	=	00A2 2024	
0x0000014	or \$8,\$4,\$2	000000	00100	00010	01000 00000 100101	=	0082 4025	
0x0000018	sll \$8,\$8,1	000000	00000	01000	01000 00001 000000	=	0008 4040	
0x000001C	bne \$8,\$1,-2 (≠,转 18)	000101	01000	00001	1111 1111 1111 1110	=	1501 FFFE	
0x00000020	slt \$6,\$2,\$1	000000	00010	00001	00110 00000 101010	=	0041 302A	
0x00000024	slt \$7,\$6,\$0	000000	00110	00000	00111 00000 101010	=	00C0 382A	
0x00000028	addi \$7,\$7,8	001000	00111	00111	0000 0000 0000 1000	=	20E7 0008	
0x0000002C	beq \$7,\$1,-2 (≠,转28)	000100	00111	00001	1111 1111 1111 1110	=	10E1 FFFE	
0x00000030	sw \$2,4(\$1)	101011	00001	00010	0000 0000 0000 0100	=	AC22 0004	
0x00000034	lw \$9,4(\$1)	100011	00001	01001	0000 0000 0000 0100	=	8C29 0004	
0x00000038	bgtz \$9,1 (>0,转 40)	000111	01001	00000	0000 0000 0000 0001	=	1D20 0001	
0x0000003C	halt	111111	00000	00000	0000 0000 0000 0000	=	FC00 0000	
0x00000040	addi \$9,\$0,-1	001000	00000	01001	1111 1111 1111 1111	=	2009 FFFF	
0x00000044	j 0x00000038	000010	00000	00000	0000 0000 0000 1110	=	0800 000E	
0x00000048	xor \$10,\$2,\$1	000000	00010	00001	01010 00000 100110	=	0041 5026	
0x0000004C	xori \$10,\$1,7	001110	00001	01010	00000 00000 000111	=	382A 0007	
0x0000050	lui \$11,15	001111	00000	01011	00000 00000 001111	=	3C0B 000F	
0x0000054	slti \$12,\$10,22	001010	01010	01100	00000 00000 010110	=	294C 0016	
0x0000058	sllv \$13,\$2,\$12	000000	00010	01100	01101 00000 000100	=	004C 6804	
0x000005C	srlv \$14,\$2,\$13	000000	00010	01101	01110 00000 000110	=	004D 7006	
0x00000060	srl \$14,\$10,2	000000	00000	01010	01110 00010 000010	=	000A 7082	
0x00000064	addi \$15,\$0,0x70	001000	00000	01111	00000 00001 110000	=	200F 0070	
0x00000068	jr \$15	000000	01111	00000	00000 00000 001000	=	01E0 0008	
0x000006C	j 0x00000074	000010	00000	00000	00000 00000 011101	=	0800 001D	
0x00000070	jal 0x0000006C	000011	00000	00000	00000 00000 011011	=	0C00 001B	
0x00000074	sb \$2,5(\$1)	101000	00001	00010	00000 00000 000101	=	A022 0005	
0x00000078	lb \$10,5(\$1)	100000	00001	01010	00000 00000 000101	=	802A 0005	
0x000007C	bgez \$10,1(>=0,转 84)	000001	01010	00001	00000 00000 000001	=	0541 0001	
0x00000080	blez \$10,2(<=0,转 8C)	000110	01010	00000	00000 00000 000010	=	1940 0002	
0x00000084	sub \$10,\$2,\$1	000000	00010	00001	01010 00000 100010	=	0041 5022	
0x00000088	bltz \$10,-2(<0,转 80)	000001	01010	00000	11111 11111 111101	=	0540 FFFD	
0x0000008C	sra \$10,\$10,2	000000	00000	01010	01010 00010 000011	=	000A 5083	
0x00000090	srav \$10,\$2,\$1	000000	00010	00001	01010 00000 000111	=	0041 5007	
0x00000094						=		
0x00000098						=		
						=		

				=	
				11	
Ī				=	