Integrator's Manual ¶

Contents

- Integrator's Manual
 - Introduction
 - Hardware System Interface
 - Tree Build
 - Performance Model
 - Library Cells
 - Synthesis

Introduction

This document introduces essential knowledge for how to integrate NVDLA into an SoC. It includes detail on bus interfaces, power on sequence, address map, cell requirements, and synthesis.

The open source repository contains the NVDLA design RTL, a testbench, a performance estimation spreadheet, and a set of synthesis scripts.


Hardware System Interface

Overview

NVDLA is a fixed function accelerator engine which is targeted towards deep learning. This section introduces the NVDLA external interface and recommended connections.

System Diagram

The following diagram shows the NVDLA connections to an SoC.



NVDLA receives commands from the host processor via the CSB interface. The two independent memory interfaces provide access to storage for data feeding NVDLA and output data from NVDLA. The interrupt provides a notification to a controlling CPU that NVDLA has completed a task.

Interfaces

NVDLA's external pins are grouped into the following interfaces:

- 1. Clock and Reset interface
- 2. System Data interface
- 3. Configure interface
- 4. Interrupt interface

- 5 Power control
- 6. DFT interface

Clock and reset interface

There are two clock domains in NVDLA, dla_core_clk and dla_csb_clk. They are asynchronous with respect to each other, and have no required frequency relationship. Most of the sub-units are in dla_core_clk domain. The Csb_master sub-unit which translates configuration commands from host clock domain to dla_core_clk domain. To reduce power consumptions, clock gating technology has been deployed in NVDLA.

The main reset signal of NVDLA is dla_reset_rstn. Internal to NVDLA it's synchronized to one of the two clock domains before use. The NVDLA design utilizaes asynchronous reset flops, so only the deassertion edge of the dla_reset_rstn signal is synchronized. The assertion edge is passed through. The other reset signal, direct_reset_, is useful for ATPG testing since it bypasses the internal synchronization.

Table 61 - Clock and Reset Signals

Signal Name	Description	Recommended Connection
dla_core_clk	Functional clock for NVDLA	Always ticking clock
dla_csb_clk	CSB bus clock for NVDLA configuration, same clock domain as host	Clock of the configurable interface
global_clk_ovr_on	Can be used to disable all non-inferred clock gates. Typically not used.	Connect to a register in system controller which is reset to 0. You can also tie to low.
tmc2slcg_disable_clock_gating	Disable clock gating during DFT operations.	Connect system DFT controller, should be 0 in normal function mode.
direct_reset_	DFT reset to allow for direct reset controllability during ATPG testing.	Typically routed to a chip level port.
dla_reset_rstn	Main functional reset for DLA block.	System reset controller, can be hard-wired control logic or connect to register if SW reset is desired.

System Data Interfaces (DBBIF and SRAMIF)

NVDLA accesses external data through two data master interfaces: DBBIF and SRAMIF In the RTL these are are sometimes referred to as dbb and cvsram. Later version will likely all references to dbbif and sramif. DBBIF typically is connected to off chip DRAM and provides high bandwidth with longer latency. SRAMIF is typically connected to an on-chip SRAM and provides high bandwidth with low. In current release the bus interfaces are designed to run optimally with max latency on DBBIF of up to 1440 cycles and an SRAMIF latency of up to 128 cycles. To support the two different memory subsystem characteristics there are some minor difference in implementation between the NVDLA's bus interface logic between DBBIF and SRAMIF.

More information on the DBBIF and SRAMIF interfaces, including signal naming, can be found in the NVDLA Hardware Architecture Guide.

Configuration Interface

The host uses the CSB (Config Space Bus) interface to access NVDLA registers. Each request to CSB has a fixed request size of 32 bits of data, and has a fixed 16-bit address size. CSB does not support any form of burst requests; each packet sent down the request channel is independent from any other packet.

A detailed interface description of the configuration interface can be found in NVDLA Architecture document.

Power control

Depending on the target library the RAM cells in NVDLA could be gated to reduce power consumption when NVDLA is inactive. Each layout partition has one ram power control bus, allowing power to be ramped up/down one or more partitions at a time. If a user is using RAM cells without power controls, those signals can be tied to 0.

Table 62 - Power Control Signals

Signal Name	Description	Recommended Connection	
nvdla_pwrbus_ram_*_pd[7:0]	RAM power gate. These signals are routed to the SLEEP EN bus on the RAM macro		
	wrappers. They can be used for controlling low	SoC power management unit or tie to 0	
	power modes of the target RAMs.		

Signal Name Description		Recommended Connection
	RAM retention control. This signal is routed to	
	the RET_EN signal on the RAM macro	
nvdla_pwrbus_ram_*_pd[8]	wrappers. It can be used for controlling	SoC power management unit or tie to 0
	retention control, or any other semi-static RAM	
	configuration bit.	
nvdla_pwrbus_ram_*_pd[31:9]	Not used	Tie to 0

DFT

In current release, NVDLA has implemented one signal named test_mode to enable DFT.

Table 63 - DFT Signals

Signal Name	Description	Recommended Connection
test_mode	Enable test mode. The only use of this signal currently is to select between the functional and DFT reset signals.	Should connect to the system DFT controller as needed. Otherwise, tie to 0.

Tree Build

Please follow instructions in NVDLA Environment Setup Guide (environment_setup_guide.html), section *Tools and Dependency*Libraries Setup to setup environment and section Build test bench and run protect tests to run a small set of tests to make sure tree is in good health.

If CMOD is also be required to integrate to system level cmod environment. Please follow NVDLA Environment Setup Guide (environment_setup_guide.html), section *Build CMOD* to build CMOD headers and dynamically linked shared object.

Performance Model

Included in the repository is a spreadsheet based performance model. This spreadsheet models the performance for three popular convolutional networks: AlexNet, GoogleNet, and ResNet50. Additional networks could be added by following the structure of the three provided. Performance calculated is ideal performance as it doesn't account for some software overhead. The spreadsheet is located in the repository at hw/perf/DLA_OpenSource_Performance.xlsx. The first tab in the spreadsheet, named "Readme", describes how the model works. It calculates the following metrics.

- Average run time for a frame
- Frames per second
- Hardware MAC utilization
- · Network MAC utilization

The tool can be used to look at the affect of different hardware configurations on network performance.

Library Cells

There are a few library cells which the NVDLA design requires. These cells are instantiated by the design, but only behavioral models are provided. The integrator will need to provide a mapping to a technology library. Typically, the effort would be to create a Verilog wrapper module which has the same ports as the RTL version provided in the release, and which instantiates a standard cell or memory from a local library.

Synchronizers

The NVDLA design instantes four types of clock domain crossing synchronizers. These cells are modelled with RTL Verilog so they are synthesizable. However, like all synchronizers, they should be replaced with a standard cell designed to reduce MTBF. To replace, the RTL impelementation of the cells below can be removed (keeping the port list), and replaced with an instantiation of a standard cell synchronizer as appropriate.

• p_SSYNC2D0_C_PP

Two flop stage deep synchronizer with an active low asynchronous reset/clear pin.

p_SSYNC3D0

Three flop stage deep synchronizer.

• p_SSYNC3D0_C_PPP

Three flop stage deep synchronizer with an active low asynchronous reset/clear pin.

• p SSYNC3D0 S PPP

Three flop stage deep synchronizer with an active low asynchronous set pin.

Memories (SRAM)

The memories instantiated in the NVDLA design have a logical interface which is fairly common across RAM compilers. The release contains a behavioral model for these RAMS which can be used for simulation. For synthesis, these behavioral models will need to be replaced with a Verilog wrapper which maps to RAM cells from a local library.

All functionality for a RAM can be inferred from the RAM name:

RAM<Arch>_<Depth>X<Width>[_Options]<_Mux-Option>_<Rev> required, physical implementation of the cell: Arch -PDP pseudo-dual port SRAM. Created by double clocking a single port RAM. -DP true dual port SRAM. Always has independent read and write ports. Depth required, number of words in the RAM Width required, number of bits in the RAM Options 0 GL for all RAMs Mux-Option Required, fixed width field describing column mux options - Mn Column mux specification. Revision: E2 for DP RAMS, D2 for PDP RAMs Rev

RAMDP: Dual-Port SRAM

This section describes a dual-port SRAM design. The macro is designed to perform read and write operations independently.

Туре	Presence	Description
Re	ad/Write Pins	
Input; Clock	Default	Memory read clock
Input; Clock	Default	Memory write clock
Input	Default	Synchronous read address input
Output	Default	Memory read data output
Input	Default	Synchronous read enable
Input	Default	Synchronous write address input
Input	Default	Synchronous write data input
Input	Default	Synchronous write enable
These will depend on the ta	arget RAM library fo	or whether they are necessary.
Input	Default	Asynchronous stand-by mode enable pin
Input	Default	Power gating controls
Input	Default	Retention enable
Input	Default	Timing margin control pins
	Input; Clock Input; Clock Input Output Input	Read/Write Pins Input; Clock Default Input; Clock Default Input Default Output Default Input Default These will depend on the target RAM library for Input Default Input Default Input Default Input Default Input Default

RAMDP is a true dual port high density SRAM, which allows read and write to operate at the same time.

All write operations are synchronized to the rising edge of write memory clock, CLK_W. The SRAM core is written when WE = '1'.

Read operation is synchronized to the rising edge of the read memory clock, CLK_R . The SRAM core is read when RE = '1'. A latch holds the read data whenever RE = '0'. There is no write through capability. If the read address matches the write address, read out data may be corrupted.





Fig. 83 - Dual Port RAM Read Timing



RAMPDP: Pseudo-Dual Port SRAM


This section describes an embedded pseudo-dual port SRAM macro. The RAMPDP macro behaves like a dual port RAM, but is created by double clocking a single port RAM.

The following enumerates the RAMPDP pins and corresponding functions.

Note that: * All pin power is referenced to VDD. * All enables are active high.

Pin	Туре	Presence	Description
		Read/Write Pins	
CLK	Input; Clock	Default	Memory clock

Pin	Туре	Presence	Description
RADR_[msb:0]	Input	Default	Synchronous read address input
RD_[msb:0]	Output	Default	Memory read data output
RE	Input	Default	Synchronous read enable
WADR_[msb:0]	Input	Default	Synchronous write address input
WD_[msb:0]	Input	Default	Synchronous write data input
WE	Input	Default	Synchronous write enable
Misc. Pins.	These will depend on the ta	rget RAM library fo	r whether they are necessary.
IDDQ	Input	Default	Asynchronous stand-by mode enable pin
SLEEP_EN_[7:0]	Input	Default	Power gating controls
RET_EN	Input	Default	Retention enable
RET_SVOP[1:0]	Input	Default	Timing margin control pins



(../../_images/ig_sram_pdp_timing1.png)

Fig. 85 - Pseudo Dual Port RAM Timing

The RAMPDP behaves like a dual port RAM, but is created by double clocking a single port RAM. It can perform a 'single read' [1R], a 'single write' [1W] or a 'read followed by write' [1R+1W] operation in any given clock cycle. A read operation is performed when the signal RE is active high [RE= '1']. The output data will be driven to the output port RD in the same cycle read commands are issued. A latch holds the read data when 'RE'=0. A write operation is performed when WE is high [WE= '1']. The input data must be put on the input data bus WD at the same time with the write command. Note that if the read and write address match during a [1R+1W] operation, i.e. RE=WE='1', the read data will contain the previous contents of the RAM (read occurs before write).

Synthesis

Overview

This release contains reference synthesis setup for the NVDLA design with Design Compiler (Wireload Model/Topographical).

Directory structure

The release directory structure for synthesis is shown below:

```
<NVDLA_RELEASE>
  |--- syn
  |--- scripts
         --- syn_launch.sh
          |--- default_config.sh
          |--- dc_run.tcl
          |--- dc_interactive.tcl
          `--- dc_app_vars.tcl
  |--- templates
          |--- config.sh
          `--- cg_latency_lut.tcl
   `--- cons
          |--- NV_NVDLA_partition_a.sdc
          |--- NV_NVDLA_partition_c.sdc
          |--- NV_NVDLA_partition_m.sdc
          |--- NV_NVDLA_partition_o.sdc
          `--- NV_NVDLA_partition_p.sdc
```

NV_NVDLA_partition_* are synthesis "TOP_NAMES" - The designs will be compiled at this hierarchy, and netlists will be generated for these designs. These are independent sub-designs for synthesis, which are instantiated in a top-level wrapper.

Requirements

You will need a *NIX machine able to run Design Compiler. The scripts have been tested with Design Compiler version 2016.12 and newer. Memory and CPU requirements vary.

Synthesis Configuration

To be able to run synthesis, you will need a config file - You can use the "<NVDLA_ROOT>/syn/dc/templates/config.sh" file as reference. This file is in "bash" syntax.

There are many required and optional variables. Table below lists the supported variables, meanings and defaults.

Table 64 - Design Related Options

Variable	Comments
NVDLA_ROOT	Location on disk for the NVDLA source "hw" directory.
	Space separated list of TOP_NAMES to synthesize. You may choose to synthesize all or a subset of
TOP_NAMES	TOP_NAMES. Defaults to "NV_NVDLA_partition_a NV_NVDLA_partition_c NV_NVDLA_partition_o
	NV_NVDLA_partition_m NV_NVDLA_partition_p"
	Space separated list of search paths (directories) for locating all the pieces of RTL. Defaults to an
RTL_SEARCH_PATH	empty string. Please do not include paths to non synthesizable (behavioral) RAM models, like the
	onesin \${NVDLA_ROOT}/vmod/rams/model
DTI TNCLUDE CEARCH DATH	Space separated list of search paths (directories) for locating all the supplementary Verilog
RTL_INCLUDE_SEARCH_PATH	include files. Defaults to an empty string.
CVTDA DTI	List of files to read in, apart from the modules that can be found in the search paths. Defaults to an
EXTRA_RTL	empty string.
RTL_EXTENSIONS	List of extensions for the source RTL files. Defaults to ".v .sv .gv"
RTL_INCLUDE_EXTENSIONS	List of extensions for supplementary Verilog include files. Defaults to ".vh .svh"
	Path to directory containing floorplans in the "DEF" format. Files should be named by the
	TOP_NAMES, with the extension ".def" This variable defaults to a directory called "def" in the
DEF	current directory
DLI	
	We do not provide templates, because it depends on the process node, and the memory compiler
	being used.

Variable		Comments
		Path to directory containing constraints in the "SDC" format. Files should be named by the
		TOP_NAMES, with the extension ".sdc" This directory may also contain " <top_name>.tcl" to</top_name>
		specify any non-SDC constraints to guide synthesis. All of these constraints are sourced before
C	ONS	compiling the design. This variable defaults to a directory called "cons" in the current directory.
		We provide template SDCs for all logical partitions in the \${NVDLA_ROOT}/syn/cons directory
		including clock constraints etc. You may provide your own constraints, based on the process node
		you are targeting.

Table 65 - Tool Related Options

Variable	Comments
DC_PATH	Location of the Design Compiler installation. Defaults to an empty string

Table 66 - Library Related Options

Variable	Comments
TARGET_LIB	Path to a single standard cell library that will be used to map the design to (the "target" library). Defaults to an empty string.
LINK_LIB	Path to all the libraries that are required to link the design. This should include the target library as well. Include any RAM compiler timing libraries here. Defaults to an empty string.
TF_FILE	Path to the "Milkyway Technology File" that is used to create the Milkyway models for the physical library. Please check with your standard cell library vendor for the right file to use. Defaults to an empty string. Required for DC-Topographical
TLUPLUS_FILE	Path to the "TLUPlus" files that will be used for RC extraction Please check with your standard cellibrary vendor for the right file to use. Defaults to an empty string. Required for DC-Topographical
TLUPLUS_MAPPING_FILE	Path to the "Tech2ITF" mapping file, that maps layer names from between the Milkyway Tech file and the interconnect technology format file. Please check with your standard cell library vendor for the right file to use. Defaults to an empty string. Required for DC-Topographical
MIN_ROUTING_LAYER	Bottom routing layer for signal nets. Please check with place-and-route methodology for the righ value. Defaults to an empty string. Required for DC-Topographical
MAX_ROUTING_LAYER	Top routing layer for signal nets. Please check with place-and-route methodology for the right value. Defaults to an empty string. Required for DC-Topographical
HORIZONTAL_LAYERS	Space separated list of layers with preferred horizontal routing. Defaults to an empty string.
VERTICAL_LAYERS	Space separated list of layers with preferred vertical routing. Defaults to an empty string.
DONT_USE_LIST	Space separated list of regular expressions for cells that you do not wish to map your design to. A "dont_use" will be applied on these cells in Design Compiler. Defaults to an empty string.
WIRELOAD_MODEL_FILE	A file containing a "wireload model" - a lookup table for resistance and capacitance calculation based on fanout. Refer to the lcug16_Defining_Wire_Load_Groups.htm on the Synopsys Solvnet site for more information regarding wire load modeling. Not required if your standard cell library contains the wireload models built in. Not required for DC-Topographical. Defaults to an empty string.
WIRELOAD_MODEL_NAME	Name of the wireload model lookup table (if you have multiple tables) Not required for DC- Topographical. Defaults to an empty string.

Warning

We do not supply timing models or synthesizable RTL for the RAMs in the design. These need to be provided by the user for the process node/memory compiler being used.

Please DO NOT include \${NVDLA ROOT}/vmod/rams/model in the RTL SEARCH PATH - They are simulation models, not synthesizable.

Table 67 - Miscellaneous Options

Variable	Comments
TIGHTEN_CGE	Boolean, "1" to enable over constraining the CG-Enable paths. See section 5.5.2 below Default is set to "0"
CGLUT_FILE	File containing the fanout-based CG over constraint lookup table to pessimize the CG enable paths. See section 5.5.2 below. Please see "\${NVDLA_ROOT}/syn/templates/cg_latency_lut.tcl" for an example. Defaults to an empty string.
DC_NUM_CORES	The number of CPU cores available for Design Compiler. Defaults to '1' Note: Single CPU core synthesis may see a long overall runtime.
AREA_RECOVERY	Boolean, "1" to Run quick area optimization by undoing some optimizations on paths with positive slack. Defaults to "1".
INCREMENTAL_RECOMPILE_COUNT	Number of rounds of incremental compiles to run in Design Compiler. Defaults to "1" - This amounts to 2 rounds of compile, one for mapping - the "main" compile and one for incremental optimization - the "incremental" compile.
COMMAND_PREFIX	String. Defaults to an empty string. This will be pre-fixed to the dc_shell command. Use this to manage job submission on LSF farm or grid, as appropriate. Use literal strings " <module>" and "<log>" to substitute module name and log directory for each TOP_NAMES. In the absence of a command prefix, the synthesis jobs for each TOP_NAMES will run serially. If you do provide a command prefix, make sure that it is non-blocking, so that all synthesis jobs can be parallelized. Otherwise, the jobs are run serially. Example:</log></module>
	export COMMAND_PREFIX="bsub -q some_queue -o <log>/<module>.1sf.log"</module></log>

Synthesis constraints

Clock Constraints

The clock constraints are provided through an SDC file. You will find reference constraints in

"\${NVDLA_ROOT}/syn/cons/NV_NVDLA_partition*.sdc". These contain clock targets for the 16nm process. You will need to scale the clock constraints to the target process/synthesis corner as appropriate. The SDC files also contain some timing exceptions (false paths) as well. Please populate the SDC files for all TOP_NAMES in a single directory, and set the CONS variable in the configuration file described in the previous section.

You can also add additional non-SDC constraints, like, for example, specific clock gating styles, etc. in <CONS>/NV_NVDLA_partition*.tcl

Clock Gate Enable Path Over constraining

The flow allows for over constraining the CG enable paths to pessimize synthesis to take into account post-CTS latencies. This is achieved through a fanout-based lookup table in TCL syntax. See "\${NVDLA_ROOT}/syn/templates/cg_latency_lut.tcl" for an example. Provide the path to this file as the CGLUT_FILE variable in the configuration file. To enable the over constraining, please set TIGHTEN_CGE variable to 1 in the configuration file.

Physical Constraints

If you are running physical synthesis, you can provide floorplans in DEF syntax for RAM/IO placement as input, depending on your physical implementation. Populate the DEF files for all TOP_NAMES in a single directory, and provide the path to the directory as the DEF variable.

You can also provide constraints in TCL syntax, through "<CONS>/NV_NVDLA_partition*.tcl" files.

Running synthesis

You can run synthesis using the "\${NVDLA_ROOT}/syn/dc/scripts/syn_launch.sh" bash script. The supported arguments to the scripts are in table below.

Table 68 - Miscellaneous Options

Argument Explanation

-config Path to the synthesis configuration file (see section 5.4) If not provided, the flow will look for a file called "config.sh" in the current directory.

Specifies which tool to use for synthesis. Use one of the following:

-mode

-build Sandbox of synthesis. Optional. Defaults to "nvdla_syn_<timestamp>"

- Space separated list of modules to run synthesis on / restore database for. If not specified, the TOP_NAMES must be modules

- populated in the configuration file.

- Path to design database (in DDC format) to restore.

Running Non-physical synthesis (Wireload Models)

You can run:

```
${NVDLA_ROOT}/syn/dc/scripts/syn_launch.sh -mode wlm -config /path/to/config.sh
```

You will need to have a wire load model defined in your standard cell library, or in a separate file (in liberty syntax, as described in the lcug16_Defining_Wire_Load_Groups.htm on Synopsys solvnet)

In the configuration file the following variables are required to be defined:

```
WIRELOAD_MODEL_NAME
TARGET_LIB
LINK_LIB
DC_PATH
```

The following variables are optional:

```
WIRELOAD_MODEL_FILE
```

Running physical synthesis

You can run one of the following, To pick DC-Topographical/DC-Graphical/DC Explorer:

```
${NVDLA_ROOT}/syn/dc/scripts/syn_launch.sh -mode dct -config /path/to/config.sh
${NVDLA_ROOT}/syn/dc/scripts/syn_launch.sh -mode dcg -config /path/to/config.sh
${NVDLA_ROOT}/syn/dc/scripts/syn_launch.sh -mode de -config /path/to/config.sh
```

In the configuration file, the following variables are required to be defined:

```
TARGET_LIB
LINK_LIB
MW_LIB
DC_PATH
TF_FILE
TLUPLUS_FILE
TLUPLUS_MAPPING_FILE
MIN_ROUTING_LAYER
MAX_ROUTING_LAYER
```

Additionally, you may require the following variables depending on how your physical library views were built:

```
HORIZONTAL_LAYERS
VERTICAL_LAYERS
```

Restoring a design database

You can run one of the following, To restore a design database from a previous synthesis run with the reference methodology:

```
${NVDLA_ROOT}/syn/dc/scripts/syn_launch.sh -mode <mode_used_for_synthesis> -config /path/to/config.sh -build
```

Synthesis outputs

In the synthesis sandbox, the following outputs are generated:

```
<BUILD>
  |--- fv
        `--- NV_NVDLA_parition*
                 `--- NV_NVDLA_parition*.svf
  |--- net
        |--- NV_NVDLA_partition*.gv (Mapped Netlist)
        |--- NV_NVDLA_partition*.full.def (complete output DEF)
        `--- NV_NVDLA_partition*.sdc (Output SDC)
        `--- NV_NVDLA_partition*.ddc (Synthesis design Database)
  (There are also a few intermediate design databases here)
   `--- report
           |--- NV_NVDLA_partition*.check_design
           |--- NV_NVDLA_partition*.check_timing
           `--- NV NVDLA partition*.final.report
                      (Detailed timing/QoR information)
                      (There are also reports generated at intermediate stages)
```

Here is the end of Integrator's Manual.