

ARM MOUNT INSERTS — 1 / 0.5 (#92011)

WAGONER DESIGNS RACING ENGINEER · HALF-STEP PILLS

Associated pack #92011 is eight black plastic inserts. They sit in the same arm-mount grid as the stock 1-degree pills, but they split a click so you can land between the usual 1-up and 1-corner holes.

As molded, the hinge pin sits 1 degree (0.7 mm) up from center and 0.5 degree (0.35 mm) in or out. Flip the insert on its side and you get 1 degree out with a 0.5 degree up or down.

There are two cavities — Type 1 and Type 2. The holes are mirrors. One of each type goes in a mount, and they have to face each other or the pin will bind. Read the map before you press them in.

These pills fit the RC10 B6 family, B74, T6.1, SC6.1, and the B64 series.

INSERT MAP — BLACK CELLS ARE 1 / 0.5 (#92011)



TYPE 1

1° / 0.7 mm UP
0.5° / 0.35 mm RIGHT



TYPE 2

1° / 0.7 mm UP
0.5° / 0.35 mm LEFT

- One Type 1 and one Type 2 per arm mount.
- Match the clocking. Left and right have to mirror.
- Black cells on the map are the 1 / 0.5 pills.
- White cells are the stock 1.0 and 0.5 holes
- already in the kit grid.

WHEN THE HALF STEP IS THE RIGHT CLICK

1. Wide pins already at 1-out C and 1-out D, and you only want a half click of anti-squat. The black insert lets you go 0.5 up or down instead of a full degree.
2. You are 1-up and middle at 3.0 toe and you want 2.5. Put the 1 / 0.5 out in the C block. Anti-squat stays at 1, toe lands on 2.5.