BO1V3-01

# **INSTALLATION**

## 1. INSTALL[NO.2[ROOF[DRIP[\$IDE[FINISH[MOULDING[CLIP

If the No.2 toof drip side tinish moulding tip comes off.

(a) Using a heat light, the at the body mounting surface to 40 - 60 C 104 - 140 F).

#### **NOTICE:**

### Do not heat the body excessively.

- (b) Remove the adhesive tape and adhesive from the body.
- (c) Wipe off stains with cleaner.
- (d) Using a heat light, heat the body and moulding blip.

Body: 40 - 60 C (104 - 140 F) Moulding: 20 - 30 C C 68 - 6 F)

### **NOTICE:**

### Do[hot[heat[the[body[and[moulding[excessively.

- (e) Install the clip.
- 2. INSTALL ROOF DRIP SIDE FINISH MOULDING
- 3. w/o[Roof[Rail,[Roof[Rack: INSTALL[NO.2[ROOF[DRIP[SIDE[FINISH[CENTER[MOULDING]
- 4. w/ Roof Rail:

INSTALL[ROOF[RAIL[(See]page[BO-227)]

5. w/ Roof Rack:

INSTALL[ROOF[RACK[See]page[BO-228]