29 LAND CRUISER (RHD) Power Source Remote Control Mirror (w/o Driving Position Memory) 3 2 (*1) R 9 Remote Control Mirror SW (*2, *3) ACC /Up 13 IF2 I26 Ignition SW LH Q LH γ 39 (2E) 44 (2Q) MLH MLV MRH M+ Engine Control and Fuel Tank Changeov System<8-3> (\$\hat{\tilde{\chi}}\text{B} 4 IF2 15 IF2 5 IF2 16 IF2 19 IF2 50 (3Q) 22 IF2 11 IF2 1(2C) J27 Junction 10 8**(**3J**)** 52 (3Q) 1(3C) 31 (3Q) 32**(**3Q) SB J25 Junction SB 3 IV1 (*1) 47 2Q 11 2J 48 2Q 4 (2Q) 5 (2Q) 66 3Q 57 (3Q) (*4) 11 (3J) 4(2J) 14(2J) 13**(**2J**)** * 1 : w/ Retractor (%) ₽ * 2 : 2UZ-FE A/T * 3 : 2UZ-FE M/T * 4 : Except 2UZ-FE **+** \bigcirc (*2, *3) 7 Set Bolt of Cowl Side J/B LH Set Bolt of Cowl Side J/B LH R49 Remote Control Mirror RH R48 Remote Control Mirror LH