42 LAND CRUISER (RHD) Power Source Power Seat (w/o Driving Position Memory) 2 B-G P24 Power Seat Control SW (Front Passenger' s Seat) 30A RH SEAT 30A LH SEAT Rear Vertical Ь SLDF SLDR FUP FDWN RCLF LUP 10 BU2 L 4 Lumbar Support Control SW (Driver's Seat) P33 Power Seat Motor (Front Passenger's Seat (Front Passenger's Seat (Front Passenger's Seat (Front Passenger)) P23 Power Seat Control SW (Driver' s Seat) Rear Vertical 1 BT1 2 BT1 SLDF SLDR FUP FDWN RCLF RCLR LUP LDWN P31 Power Seat Motor (Driver's Seat Slide Control) P30 Power Seat Motor (Driver's Seat Reclining Control) W-B Under the Front Seat LH BJ Front Side Under the Front Seat RH