DI89H-06

## 29. Voice on Phone Cannot be Heard, too Quiet, or Distorted

## **INSPECTION PROCEDURE** 1 Check cellular phone. Check[]f[]he[]voice[]on[]he[]other[]side[]can[]be[]heard[]using[]a[]cellular[]phone. OK: Voice can be heard. NG□ Replace cellular phone. OK 2∏ Check settings (a) Check If the Volume is \$\text{10}the iminimum or imaximum \$\text{setting}. HINT: When the volume is settle in inimum or maximum setting, the sound may be distorted. (b) Check if the MUTE switch is set to ON. OK: MUTE[switch[is[not[set[to]ON. Set[mute[switch[correctly. NG∏ OK 3∏ Voice check Check if the havigation voice can be heard. OK: The voice can be heard. NG Go to "No voice navigation" (See page DI-242). OK

Replace multi-display.

LAND[CRUISER[W/G)[SUP] (RM1072E)