

- P 7 Parking Brake SW
- P 8 Power Outlet (Luggage Compartment)
- P 12 Power Window Control SW Front RH
- P 13 Power Window Control SW Rear LH
- P 14 Power Window Control SW Rear RH
- P 15 Power Window Master SW
- P 17 Power Window Motor Front LH
- P 18 Power Window Motor Front RH
- P 19 Power Window Motor Rear LH
- P 20 Power Window Motor Rear RH
- P 21 Pretensioner LH
- P 22 Pretensioner RH
- R 13 Rear A/C Control SW
- R 14 Rear Air Mix Control Servo Motor
- R 15 Rear Combination Light LH
- R 17 Rear Combination Light RH
- R 19 Rear Cooler Blower Motor
- R 20 Rear Cooler Magnetic Valve
- R 21 Rear Cooler Power Transistor
- R 22 Rear Cooler Relay
- R 23 Rear Diff. Lock Motor
- R 24 Rear Door Speaker LH
- R 25 Rear Door Speaker RH
- R 26 Rear Evaporator Temp. Sensor
- R 27 Rear Heater Blower Motor
- R 28 Rear Heater Blower Resistor
- R 30 Rear Heater Power Transistor
- R 31 Rear Heater Relay
- R 32 Rear Inlet Air Temp. Sensor
- R 33 Rear Interior Light
- R 34 Rear Personal Light
- R 37 Rear Window Defogger LH
- R 38 Rear Window Defogger LH
- R 39 Rear Window Defogger RH
- R 40 Rear Window Defogger RH
- R 42 Rear Wiper Motor LH
- R 43 Rear Wiper Motor RH
- R 44 Rear Wiper Relay
- R 47 Remote Control Mirror ECU
- R 48 Remote Control Mirror LH
- R 49 Remote Control Mirror RH
- R 50 Room Temp. Sensor (Rear)
- R 58 Rain Sensor
- R 59 Rear Cooler Blower Resistor
- R 60 Rear Fog Light























