AIR CONDITIONER DLE-UP SPEED (1HD-FTE)

INSPECTION

EMOWZ 0

- 1. ☐ INITIAL CONDITIONS
- (a) Engine at hormal operating temperature.
- (b) Air cleaner nstalled.
- (c) All pipes and hoses of air induction system connected.
- (d) Allaccessories witch OFF.
- (e) All vacuum ines properly connected.
- (f) ECD[\$ystem[wiring[connectors[fully[plugged.
- (g) Valve clearance set correctly.
- (h) Injection diming \$et correctly.
- (i) Idle speed set correctly.
- 2. CONNECT TACHOMETER

(See page EM-17)

- 3. INSPECT A/C IDLE-UP SPEED
- (a) Start the engine.
- (b) Push on the A/C switch.
- (c) Check the A/C idle-up speed.

A/C idle-up speed: 725 - 850 rpm

If the A/C idle-up speed is not specified, check the troubleshooting in DI section.