R

MODEL CODE

HZB50 R-Z E M R S Q 5

	BASIC	MODEL CODE	
	CODE	ENGINE	WHEEL BASE
	RZB40	3RZ-FE	Short
	RZB50		Long
1	BB42	14B	Short
'	BB50	15B-FT	
			Long
	BB58	15B-FTE	
	BB59		Super Long
	BZB40	1DZ EDE	Short
	BZB50	1BZ-FPE	T
	HZB50	1HZ	Long

	STEERING WHEEL POSITION
2	L: Left-Hand Drive
	R: Right-Hand Drive

	ROOF TYPE
3	B: Standard Roof
	Z: High Roof

	SEATING CAPACITY
4	C: 17 or 20 E: 19, 20, 22 or 23 G: 30 R: 26

	GEAR SHIFT TYPE
5	F: 6-Speed Manual, Floor M: 5-Speed Manual, Floor

	GRADE
6	N: DX R: Standard (Without Air Conditioner) S: Standard (With Air Conditioner) Q: EX

	ENGINE SPECIFICATION
7	C : LPG
	K : EFI
	S: Diesel
	W: Diesel, Tarbochager
	Z : EFI Diesel, Tarbochager

	DESTINATION
8	Q : Australia V : G.C.C. Counries C : China
	Blank: General Countries

9 CHASSIS MODEL/COMPLETE MODEL
5 : Super Long, Seat Less Model
1 : Europe chassis (CKD)
Blank : Complete Model