
Position of Parts in Body

[RHD : Swing Type]



- S14 Sub Fuel Pump
- S15 Sub Fuel Pump Forcing Driving Relay
- S16 Sub Fuel Sender
- S21 Side Airbag Sensor Front LH
- S22 Side Airbag Sensor Front RH
- S23 Side Airbag Sensor Rear LH
- S24 Side Airbag Sensor Rear RH
- S25 Stereo Component Amplifier
- S26 Stereo Component Amplifier

- T 19 Tweeter LH
- T20 Tweeter RH
- T26 Theft Deterrent Siren
- V18 Vanity Light LH
- V19 Vanity Light RH
- W13 Woofer (Speaker)
- Z 8 Option Connector (Microphone)
- Z 9 Option Connector (Trailer Towing)