

REASSEMBLY

BR0TI-11

Reassembly[is[in[the[reverse[order[of[disassembly[(See page[BR-29).

INSTALL_ACCUMULATOR_BRACKET

When installing the faccumulator bracket, adjust to secure the clearance shown in the flustration on the left.

Standard clearance:

A[]-[B:[4.1[mm[[0.161[]n.)[]or[]ess

C: 0.3 - 3.8 mm (0.012 - 0.150 in.)

HINT:

Secure more than 0.3 mm (0.012 in.) clearance for A and B each.