DIAWL-01

19. Navigation screen cannot change to the hight mode color.

INSPECTION PROCEDURE	
1[Check[the[setting.[(Is[it[set[to[Day[Mode[in[screen[adjustment?)
	Yes Normal.
No	
2[]	Check[]f[]the[]screen[]s[dimmed[]at[]hight.[(With[]the[]ight[]control[]switch[]ON,[]do[]all screens[]except[]the[]havigation[]screen[]appear[]n[Night[]Mode?)
	NG Go[to[step[5.
ОК	
3[]	Does[the[beep[sound[by[operating[switches[on[the[navigation[screen?
	OK Replace havigation ECU.
NG	
4	Check[]*AVC-LAN@communication@circuit**[(See@page@DI-1215)[]
	NG Replace or repair AVC-LAN circuit.
ОК	
Replace the navigation ECU.	

5 Check the multi display.

CHECK:

Check terminal DR.

<u>OK:</u>

DR: See "Multi Display" of "TERMINAL OF ECU".

OK Replace the multi display.

NG

Replace or repair wire harness.