
SR0QC-02




## INSTALLATION

## 1. INSTALL PS VANE PUMP ASSEMBLY

- (a) Coat a new O-ring with power steering fluid and install it to the vane pump assembly.
- (b) Torque the 2 nuts.

Torque: 36 N·m (370 kgf·cm, 27 ft·lbf)



## 2. CONNECT PRESSURE FEED TUBE

Install new gaskets on each side of the tube and torque the union bolt.

Torque: 50 N·m (510 kgf·cm, 37 ft·lbf)

HINT:

Make sure that the stopper of the tube touches the PS vane pump body as shown in the illustration, then torque the union bolt.

- 3. CONNECT OIL PRESSURE SWITCH CONNECTOR
- 4. CONNECT RETURN HOSE

Install the clip.

- 5. INSTALL NO.1 AND NO.2 ENGINE UNDER COVERS
- (a) Install the No.1 under cover with the 6 bolts.
- (b) Install the No.2 under cover with the 8 bolts.
- **6. INSTALL FRONT TRANSMISSION UNDER COVER** Tighten the 2 bolts and nuts.
- 7. BLEED POWER STEERING SYSTEM (See Pub. No. RM616E on page SR-4)