DI31U-05

DTC	P1122/19 Accel. Closed Position SW Circuit (Short)
DTC	P1123/19 Accel. Closed Position SW Circuit (Open)

# **CIRCUIT** DESCRIPTION

Refer[]o[DTC[]P1120/19[]on[]page[]DI-67.


DTC No.	DTC Detection Condition	Trouble Area	
P1122/19	Conditions (a) and (b) continue 0.5 sec. or more:  (a) PDL ON  (b) VA > Fully closed study voltage +0.41 V	Short in accelerator pedal closed position switch circuit     Accelerator pedal closed position switch     Engine ECU	
P1123/19	PDL does not turn ON even once while driving vehicle (2 trip detection logic)	Open in accelerator pedal closed position switch circuit	
	Conditions (a) and (b) continue 5 sec. or more: (a) PDL OFF (b) IDL ON	Accelerator pedal closed position switch     Engine ECU	

# **WIRING DIAGRAM**

Refer To DTC P1120/19 on page DI-67.

# **INSPECTION PROCEDURE**

Check accelerator pedal closed position switch.



# **PREPARATION:**

Disconnect the accelerator pedal closed position switch connector.

## **CHECK:**

Measure the resistance between terminals of the accelerator pedal closed position switch.

#### OK:

Terminals	Accelerator pedal	Resistance
1 – 2	Fully closed	10 kΩ or higher
1 – 2	Fully open	0 to 20 Ω


NG

Replace accelerator pedal closed position switch (See Pub No. RM617E, page ED-9).

ок

1

# 2 Check voltage between terminal PDL of engine ECU and body ground.



# **PREPARATION:**

- (a) Remove the glove compartment door.
- (b) Turn the ignition switch ON.

## **CHECK:**

Measure the voltage between terminal PDL of the engine ECU and body ground.

## OK:

Accelerator pedal	Voltage
Fully closed	9 to 14 V
Fully open	0 to 3 V



NG

Check for open and short in harness and connector between engine ECU and accelerator pedal closed[position[switch[and[body[ground[See]page]N-19]]]