
DIAZ4-01


## **Front Wiper Position Circuit**

## **CIRCUIT DESCRIPTION**

This signal is taken into Body ECU. If this signal cannot be received, Body ECU does not perform reverse linked function control.

## **WIRING DIAGRAM**





## INSPECTION PROCEDURE

1 Check wire harness between wiper control ECU and front wiper motor (See page IN-38).

NG□

Repair or replace wire harness.

ОК

2 Check wire harness between wiper control ECU and body ECU (See page N-38).

NG□

Repair or replace wire harness.

OK

Proceed to next circuit inspection shown on problem symptom table (See page DI-930).