## **REASSEMBLY**

TR05K-01

 $\label{lem:lemma$ 

Coat all of the sliding and rotating surfaces with gear oil before reassembly.