NEW FEATURES

ALL ENGINES

The TOYOTA genuine Super Long Life Coolant (SLLC) has been adopted. As a result, the maintenance interval has been extended.

▶ Specifications **◄**

Model						New	Previous
Engine Coolant) // /TF	LHD	5.8 (6.1, 5.1)	←
	Capacity Liters (US qts, Imp.qts)	177.1	210	M/T	RHD	5.9 (6.2, 5.2)	+
		1ZZ-FE		A //TE	LHD	5.7 (6.0, 5.0)	+
				A/T	RHD	5.8 (6.1, 5.1)	←
		3ZZ-FE		M/T	LHD	5.8 (6.1, 5.1)	+
					RHD	5.9 (6.2, 5.2)	+
		1AZ-FE		M/T	LHD	6.0 (6.3, 5.3)	+
					RHD	6.1 (6.4, 5.4)	←
				A/T	RHD	6.4 (6.8, 5.6)	←
		1AZ-FSE		M/T	LHD	6.0 (6.3, 5.3)	←
					RHD	6.1 (6.4, 5.4)	←
				A/T	LHD	6.3 (6.7, 5.5)	←
					RHD	6.4 (6.8, 5.6)	←
		2AZ-FSE		A/T	LHD	6.3 (6.7, 5.5)	_
					RHD	6.4 (6.8, 5.6)	_
		1CD-FTV		With Heater		7.6 (8.0, 6.7)	←
				Withou	t Heater	7.4 (7.8, 6.5)	←
	Туре					TOYOTA Genuine	TOYOTA Genuine
						SLLC	LLC
		First time				160,000 km	Every
	Maintenance					(100,000 mile)	40,000 km (25,000
	Intervals		Subsequent			Every 80000 km	mile) or 24 months
					(50,000 mile)	whichever comes first	
	Color					Pink	Red
Thermostat	Operating Temperature °C (°F)					80 – 84 (176 – 183)	←

- SLLC is pre-mixed (50% coolant and 50% distilled water), so no dilution is needed when adding or replacing SLLC in the vehicle.
- If LLC is mixed with SLLC, the interval for LLC (every 40,000 km/25,000 miles or 24 months) should be used.
- You can also apply the new maintenance interval (every 80,000 km/50,000 mile) to vehicles initially filled with LLC (red-colored), if you use SLLC (pink-colored) for the coolant change.