ED05R-01

INSTALLATION

INSTALL[INTAKE[MANIFOLD[WITH[INTAKE[AIR[CONTROL[VALVE (See page EM-36)]