
## **SYSTEM CIRCUIT**



## **OPERATION**

To maintain the most appropriate ignition timing, the ECU sends a control signal so that the igniter sends current to the ignition coil and the spark plugs produce a spark.

IG