
## **Connector Joining Wire Harness and Wire Harness**



Code	Joining Wire Harness and Wire Harness (Connector Location)
BS2	Floor Wire and Front Seat LH Wire (Front Side Under the Front Passenger's Seat)
BS3	