## DIAW2-01

## **PROBLEM SYMPTOMS TABLE**

Flow[chart[No. (See[page)	Component	Symptom
1. (DI-11 <u>7</u> 8)	Multi display	Black screen (Nothing displayed)
2. (DI-11 <u>7</u> 9)		No sound with Power switch pressed. ("AUTO OFF" on audio screen)
3. (DI-11 <mark>8</mark> 2)		No navigation screen displayed when "MAP", "MENU" or "DEST" switch pressed. (Screen cannot be switched.)
4. (DI-11 <u>8</u> 4)		No corresponding screen displayed when "AUDIO" or "Information" switch pressed.
5. (DI-11 <mark>8</mark> 5)		No[havigation[displayed,[]'Audio[OFF"[on[audio[screen[and[ho[audio sound.
6. (DI-11 <u>8</u> 7)		Screen cannot be dimmed in night time.
7. (DI-11 <u>8</u> 8)		Navigation screen not stabilized. (Synchronous error)
8. (DI-11 <u>B</u> 9)		Color on navigation screen is unusual (RGB signal error)
9. (DI-11 <u>9</u> 1)		Black screen appears when "MAP", "Menu" or "DEST" switch pressed.
10. (DI-11 <mark>9</mark> 2)		Sound@ff_adio,@assetteftape@r@D@nly@annotfbefheardffromspeaker.
11. (DI-11 <u>9</u> 3)		No sound (radio, cassette tape, CD) can be heard from driver side door speaker only.
12. (DI-11 <mark>9</mark> 5)		Map DISC cannot be inserted.
13. (DI-11 <u>9</u> 7)		MAP screen display does not appear. (Disc Caution screen does not change.)
14. (DI-11 <u>9</u> 8)		MAP is displayed in white or blue screen. (Switch and vehicle position mark is displayed.)
15. (DI-11 <mark>9</mark> 9)		Touch switch does not function. (Navigation screen only)
16. (DI-1 <u>2</u> 00)		Touch switch does not function. (A/C control screen only)
17. (DI-1 <u>2</u> 01)		Panel switch does not function. (Navigation screen only)
18. (DI-1 <u>2</u> 02)		Panel switch does not function. (A/C control screen only)
19. (DI-1 <u>2</u> 03)		The screen cannot be change to night mode color.
20. (DI-1 <u>2</u> 05)		Vehicle position is deviated from correct point badly.
21. (DI-1 <u>2</u> 08)		GPS mark does not appear.

22. (DI-1 <u>2</u> 10)	No voice navigation.
23. (DI-1 <mark>2</mark> 11 <u>[]</u>	Vehicle position rotates without control. (Map rotates without control)
24. (DI-1 <u>2</u> 13)	Driving direction is opposite to moving direction of vehicle position mark.
25. (DI-1 <u>2</u> 14)	Navigation system cannot be operated with voice recognition.