
Position of Parts in Body

[RHD : Liftgate Type]



- S14 Sub Fuel Pump
- S15 Sub Fuel Pump Forcing Driving Relay
- S16 Sub Fuel Sender
- S21 Side Airbag Sensor Front LH
- S22 Side Airbag Sensor Front RH
- S23 Side Airbag Sensor Rear LH
- S24 Side Airbag Sensor Rear RH
- S25 Stereo Component Amplifier
- S26 Stereo Component Amplifier
- T17 Tire Carrier Courtesy SW
- T19 Tweeter LH
- T20 Tweeter RH
- T26 Theft Deterrent Siren
- T27 Television Camera
- T 28 Television Camera ECU
- T29 Television Camera ECU

- V18 Vanity Light LH
- V19 Vanity Light RH
- W13 Woofer (Speaker)
- Z 8 Option Connector (Microphone)
- Z 9 Option Connector (Trailer Towing)