
SUSPENSION[AND[AXLE] -





## **INSPECTION**

## INSPECT[\$HOCK[ABSORBER

Compressand extend the shock absorber of and check that there is no abnormal resistance or unusual operation sounds. If there is any abnormality, replace the shock absorber with a new one.

## NOTICE:

When disposing he shock absorber, see DISPOSAL on page A-273.