RS0SJ-04

## INSPECTION

1. Vehicle inot involved in collision: INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do@diagnostic@system@heck@See@page@DI-432).

2. Vehicle involved in collision and airbag is not deployed: INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do@diagnostic@system@heck@See@page@DI-432).

3. Vehicle[involved[in[collision[and[airbag[is[deployed:

INSPECT[\$UPPLEMENTAL[RESTRAINT[\$YSTEM]

Replace the curtain shield airbag sensor assembly See page RS-96).