Ш

Ш

**CTRICAL WIRING** 

DIAGRAM

## 34 LAND CRUISER (LHD) Power Source Headlight Beam Level Control Multiplex Communication System<1–14> HEAD 10A HEAD LH–LWR H 1 Headlight Beam Level Control Actuator LH H 2 Headlight Beam Level Control Actuator RH H19 Headlight Beam Level Control SW GND F37 Fusible Link Block J25 Junction 11 IU5 (Diesel) Battery W-B Front Right Side of Fender Apron Set Bolt of Cow Side J/B LH