
l15640

COMBINATION METER



RHD models: Combination Meter Assembly Light Control Rheostat **Driver Side Junction Block** Fuel Sub Tank Switch • IGN Fuse GAUGE Fuse LHD models: DOME Fuse Ignition Switch Light Control Rheostat Body Control ECU Combination Meter Assembly Parking Brake Switch **Ignition Switch** Fuel Sub Tank Switch Seat Belt Buckle Switch

