DI6YA-01

Check for Fluid Leakage

Check for fluid leakage from actuator or hydraulic lines.



