
$\Box$ 

**HOW TO USE** 

THIS MANUAL



[A]: System Title

**[B]**: Indicates the wiring color.

Wire colors are indicated by an alphabetical code.


B = Black W = White BR = Brown L = Blue V = Voilet SB = Sky BlueR = Red G = Green LG = Light Green

P = Pink Y = Yellow GR = Gray

O = Orange

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L-Y




- [C]: The position of the parts is the same as shown in the wiring diagram and wire routing.
- [D]: Indicates the pin number of the connector.

  The numbering system is different for female and male connectors.

Example: Numbered in order from upper left to lower right

Numbered in order from upper right to lower left





Male


Female

The numbering system for the overall wiring diagram is the same as above.


[E]: Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example: 1 Indicates Relay Block No.1

[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.



- [G]: Indicates related system.
- [H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows ( ≥ ). Outside numerals are pin numbers.




- [I] : ( ) is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- [J] : Indicates a shielded cable.




- [K]: Indicates and located on ground point.
- [L] : The same code occuring on the next page indicates that the wire harness is continuous.

## **B HOW TO USE THIS MANUAL**



Junction connector in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.



## **WIRE COLOR AND TERMINAL NUMBER**

In some parts of the instrumental panel wiring harness, the same wire color (i.e. SB: Sky Blue) is used for all the wiring to a specific connector.

In order to identify the wiring, the terminal number is printed on the wiring.

Install the wiring to the connector position with the same terminal number.

Some early production Vehicles may not have these terminal numbers printed.