

2. System Diagram



- *1: For the gasoline engine model, controlled at the engine ECU. For the diesel engine model, controlled at the air conditioner ECU.
- *2: Only for Diesel Engine Model.

Automatic Air Conditioner System Model



Manual Air Conditioner System Model

258RV58