
Connector Joining Wire Harness and Wire Harness



- * 1:w/ Navigation System * 2:w/o Navigation System

Code	Joining Wire Harness and Wire Harness (Connector Location)
BG1	Frame No.3 Wire and Frame Wire (Near the Right Rear Suspension Support)
BG2	
BI1	Frame Wire and Floor No.3 Wire (Left Side of Rear Floor Crossmember)
BI2	
BI3	
BK1	Pillar No.1 Wire and Back Door Upper Wire (Left Side of Back Door)
BK2	
BM1	Floor No.2 Wire and A/C Sub Wire (Right Rear Side Quarter Panel)
BO1	Floor No.2 Wire and Floor No.3 Wire (Right Side of Rear Floor Crossmember)
BO2	
BO3	
BO4	