SS123-01

TORQUE SPECIFICATION

Part <u>¶</u> ightened		N·m	kgf∙cm	ft·lbf
Drain[and[filler[plug		37	380	27
Lever[lock[bin		12	120	9
Oil@eceiver[x[Front[case		12	120	9
Case[cover]x[Rear[case		37	380	27
Rear[extension[housing[x]Rear[case		37	380	27
Front[extension[housing[x[Front[case		37	380	27
Transfer[4WD[position[switch		37	380	27
L4[position[switch		37	380	27
Neutral[position[switch		37	380	27
Screw[plug		19	190	14
Output[shaft[]ock[]nut		127	1,300	94
Speed[sensor[driven[gear[set[bolt		11	115	8
Oil receiver pipe x Rear case	Bolt A	12	120	9
(See[page[TR-3)[]	Bolt <u>∏</u> B	18	185	13
Front case x Rear case		37	380	27
Oil receiver pipe x Front extension housing		4.9	50	43 in.·lbf