

## 7. Cooling System

- The cooling system is a pressurized, forced-circulation type.
- A thermostat with a bypass valve is located on the water inlet housing to maintain suitable temperature distribution in the cooling system.
  - This prevents sudden jumps in temperature while the engine is warming up.
- The flow of the engine coolant makes a U-turn in the cylinder block to ensure a smooth flow of the engine coolant. In addition, a bypass passage is enclosed in the cylinder head and the cylinder block.
- Warm water from the engine is sent to the throttle body to prevent freeze-up.





## **▶** Specifications **◄**

Engine Coolant	Capacity	liters (US qts, Imp. qts)	M/T	6.6 (7.0, 5.8)
			A/T	6.8 (7.2, 6.0)
	Туре		TOYOTA Super Long Life Coolant	
Thermostat	Opening Temperature	°C (°F)	80 – 84 (176 – 183)	

## **Super Long Life Coolant**

Genuine Toyota SLLC (Super Long Life Coolant) has been adopted. As a result, the maintenance interval has been extended. For detailed specifications, refer to page 417.