
Position of Parts in Instrument Panel

[RHD 1]



Code	English	Deutsch
A 17 A 26 A 27 A 28 A 29 A 30 A 31 A 32	Accel Position Sensor A/C Solar Sensor A/C Thermistor ABS Deceleration Sensor ABS ECU ABS ECU ABS ECU ACCELERATION SENSOR	Gaspedalpositionssensor A/C-Sonnensensor A/C-Thermistor ABS-Verzögerungssensor ABS-ECU ABS-ECU ABS-ECU Gaspedalschalter