HOW TO TROUBLESHOOT ECU CONTROLLED SYSTEMS

GENERAL INFORMATION

IN00Z-68

Allarge in umber of ECU controlled systems are used in the LAND CRUISER (Station Wagon). In general, the ECU controlled system sconsidered to be a very intricate system requiring a high evel of technical knowledge and expert kill of roubleshoot. However, the fact is that if you proceed to inspect the circuits one by one, I roubleshooting of these systems is not complex. If you have adequate understanding of the system and basic knowledge of electricity, accurate diagnosis and necessary repair and be performed to locate and fix the problem. This manual sedesigned through emphasis of the bove standpoint of helps ervice technicians or maccurate and effective troubleshooting, and sompiled for the following in a jor ECU controlled systems:

The froubleshooting procedure and how formake use of itare described on the following pages.

System	Page
1. Automatic Transmission (A750F for 2UZ-FE)	DI-1
2. Automatic Transmission (A750F for 1HD-FTE)	DI-29
3. ABS & Hydraulic Brake Booster Power Supply System	DI-53
4. ABS & Vehicle Stability Control (VSC) & Brake Assist (BA) System	DI-74
5. Variable Gear Ratio Steering	DI-88
6. Navigation System	DI−1 <u>r</u> 3
7. Rear View Monitor System	DI-280

FOR USING HAND-HELD TESTER

- Before using the tester, the tester's operator manual should be read thoroughly.
- If the tester cannot communicate with ECU controlled systems when you have connected the cable
 of the tester to DLC3, turned the ignition switch ON and operated the tester, there is a problem on the
 vehicle side or tester side.
 - (1) If communication is normal when the tester is connected to another vehicle, inspect the diagnosis data link line (Bus⊕line) or ECU power circuit of the vehicle.
 - (2) If communication is still not possible when the tester is connected to another vehicle, the problem is probably in the tester itself, so perform the Self Test procedures outline in the Tester Operator's Manual.