POWER TILT AND POWER TELESCOPIC STEERING **COLUMN**

COMPONENTS

Column Upper Cover Column Lower Cover Steering Column Assembly Hose Clamp No.2 Hole Cover Hole Cover Cluster Finish Panel Lower No.1 Panel Fuel Lid Release Lever



