6 LAND CRUISER (LHD) Power Source Fuel Heater Glow Plug (1HZ) 2 3 * 1 : w/o Emission Control * 2 : w/ Emission Control B-R (*1) P 1 Pick-<u>Up</u> Sensor IG2 ST2 B-W I26 Ignition SW (° ± 2 10**6**D 39 **2E** 37 (2E) 11 (2A) (3E) 7 (30) 8(3E) SREL CHG 8 lh1 GIND 1 (2C) B-R 1 If4 BR-W 1 IN6 F12 Fuel Cut Valve Controller (* 1) G B , C16(B), C18(D) lation Meter IMMO 120A J/B NO. 18 D 120A MAIN 8 IV1 W-B Battery Battery BR Set Bolt of Cowl Side J/B LH Front Left Side of Fender Apron Rear Bank of Left Cylinder Head EE