DI0DV-07

PROBLEM SYMPTOMS TABLE

Perform[]roubleshooting[]of[]he[]circuit[]or[]he[]applicable[]problem[]symptom[]n[]he[]prder[]given[]n[]he[]chart[]below.[]Proceed[]or[]he[]page[]ocated[]or[]each[]circuit.

HINT:

- Troubleshooting of the wireless door ock control system is based on the premise that the door ock control system and the tideterrent system are operating from ally. Accordingly, before troubleshooting the wireless door ock control system, first make the time door of bck control system and the tideterrent system are operating from ally.
- If [] the instruction is proceed it of the continuation is proceed in the continuation of the continuati
- If the trouble still reappears even through there are no abnormalities in any of the other circuits, wheck and replace the Wireless Door Lock ECU as the last step.

Symptom	Suspect Area	See page
All function of wireless door lock control system do no operate.	1. ECU Power Source Circuit.	DI-601
	2. Ignition Switch Circuit.	DI-604
	3. Door Courtesy Switch Circuit.	DI-617
	4. Door Key Lock and Unlock Switch Circuit.	DI-609
	(Unlock[\$ide)	
	5. Door Key Lock and Unlock Switch Circuit.	DI-612
	(Lock[\$ide)	
	6. Key Unlock Warning Switch Circuit.	DI-615
	7.[Wireless[Door[Lock[ECU.	IN-35
Only door unlock operation is not possible (Lock operation is possible).	Door Key Lock and Unlock Switch Circuit	DI-609
	(Unlock Side)	
	2. Door Unlock Detection Switch Circuit	DI-606
	3. Wireless Door Lock ECU.	IN-35
Only door lock operation is not possible (Unlock operation is possible).	Door Key Lock and Unlock Switch Circuit	DI-612
	(Lock Side)	
	2. Wireless Door Lock ECU	IN-35
Only transmitter misoperation prevention function is not possible.	Key Unlock Warning Switch Circuit	DI-615
	2. Wireless Door Lock ECU	IN-35
Wireless door lock function operates even when each door is opened.	Door Courtesy Switch Circuit	DI-617
	2. Wireless Door Lock ECU	IN-35
Wireless door lock functions incorrectly.	Door Unlock Detection Switch Circuit	DI-606
(Although one door is unlocked, when the transmitter switch is pressed, all doors unlock.)	Door Unlock Detection Switch Circuit Wireless Door Lock ECU	
	2. WITCHESS DOOF LOCK ECO	IN-35
Wireless door lock operates, but the taillight does not respond.	Taillight Relay Circuit	DI-620
	2. Wireless Door Lock ECU	IN-35